



-power in control



PARAMETER LIST



Compact Genset Controller, CGC 400

- Alarm list
- Parameter list



DEIF A/S · Frisenborgvej 33 · DK-7800 Skive
Tel.: +45 9614 9614 · Fax: +45 9614 9615
info@deif.com · www.deif.com

Document no.: 4189340789A
SW version:

1. General information

1.1. Warnings, legal information and safety.....	4
1.1.1. Warnings and notes	4
1.1.2. Legal information and disclaimer	4
1.1.3. Safety issues	4
1.1.4. Electrostatic discharge awareness	4
1.1.5. Factory settings	5
1.2. About the Parameter List.....	5
1.2.1. General purpose of the Parameter List.....	5
1.2.2. Intended users.....	5
1.2.3. Contents and overall structure	5

2. Alarm list

2.1. General information about the alarm list.....	6
2.1.1. Alarm list features and options	6
2.2. Protection parameters.....	8
2.2.1. Reverse power and overcurrent protection.....	8
2.2.2. Voltage protections.....	12
2.2.3. Frequency protections.....	14
2.2.4. Busbar voltage protections.....	17
2.2.5. Busbar frequency protections.....	19
2.2.6. Overload protections.....	21
2.2.7. Undervoltage and reactive power low.....	23
2.3. Breaker control parameters.....	25
2.3.1. Breaker alarms.....	25
2.4. Input/output parameters, binary input setup.....	28
2.4.1. Digital input 10-15 and 56-57 setup.....	28
2.4.2. Digital input 6-8 setup.....	29
2.4.3. Emergency stop.....	30
2.4.4. M-Logic alarm 1-5 setup	31
2.5. Analogue input setup.....	32
2.5.1. Multi-input no. 6.....	32
2.5.2. Multi-input no. 7	37
2.5.3. Multi-input no. 8.....	42
2.5.4. Speed and running feedback setup.....	47
2.5.5. Differential measurement.....	50
2.5.6. Aux. supply setup.....	53
2.5.7. Multi-input no. 58.....	54
2.5.8. Multi-input no. 59.....	59
2.6. System parameters, general setup.....	64
2.6.1. Engine heater failure.....	64
2.6.2. Max. ventilation.....	65
2.6.3. Switchboard error - Block and Stop.....	66
2.6.4. Switchboard error - Not in auto.....	67
2.6.5. Avg U BB.....	68
2.7. System parameters, communication.....	69
2.7.1. External communication error.....	69
2.7.2. Engine interface communication alarms.....	70

3. Parameter list

3.1. General information about the parameter list.....	74
3.1.1. Parameter list settings.....	74
3.2. Control parameter, regulation.....	75
3.2.1. Regulation.....	75
3.3. Control parameters, output setup.....	76
3.3.1. Digital output setup.....	76
3.4. System parameters.....	77
3.5. System parameters, general setup.....	78

3.5.1. General setup.....	78
3.5.2. Counters and timers.....	81
3.5.3. Alarm horn.....	82
3.5.4. Run coil setup.....	82
3.5.5. Running, start and stop.....	83
3.5.6. Breaker control.....	85
3.5.7. Idle start.....	85
3.5.8. Engine heater.....	86
3.5.9. Cooling ventilation.....	86
3.5.10. Summer/winter time.....	86
3.5.11. Fuel transfer pump logic.....	87
3.5.12. Alarm jump.....	87
3.5.13. Command timers.....	88
3.6. System parameters, mains setup.....	89
3.6.1. Test.....	89
3.6.2. Mains failure.....	90
3.7. System parameters, external communication.....	91
3.7.1. External communication.....	91
3.8. System parameters, engine interface communication.....	92
3.8.1. Engine interface communication.....	92
3.9. System parameters, setup menu.....	93
3.9.1. Password config.	93
3.9.2. AC config.....	93
3.9.3. Display control	93
3.10. System parameters, RMI inputs.....	94
3.10.1. RMI 6.....	94
3.10.2. RMI 7.....	95
3.10.3. RMI 8.....	95
3.10.4. RMI 58.....	96
3.10.5. RMI 59.....	96
3.10.6. Multi-input selections.....	97
3.10.7. Analogue unit input scaling.....	98

1. General information

1.1 Warnings, legal information and safety

1.1.1 Warnings and notes

Throughout this document, a number of warnings and notes with helpful user information will be presented. To ensure that these are noticed, they will be highlighted as follows in order to separate them from the general text.

Warnings



Warnings indicate a potentially dangerous situation, which could result in death, personal injury or damaged equipment, if certain guidelines are not followed.

Notes



Notes provide general information, which will be helpful for the reader to bear in mind.

1.1.2 Legal information and disclaimer

DEIF takes no responsibility for installation or operation of the generator set. If there is any doubt about how to install or operate the engine/generator controlled by the unit, the company responsible for the installation or the operation of the set must be contacted.



The unit is not to be opened by unauthorised personnel. If opened anyway, the warranty will be lost.

Disclaimer

DEIF A/S reserves the right to change any of the contents of this document without prior notice.

1.1.3 Safety issues

Installing and operating the unit may imply work with dangerous currents and voltages. Therefore, the installation should only be carried out by authorised personnel who understand the risks involved in working with live electrical equipment.



Be aware of the hazardous live currents and voltages. Do not touch any AC measurement inputs as this could lead to injury or death.



DEIF do not recommend to use the USB as the primary power supply for the unit.

1.1.4 Electrostatic discharge awareness

Sufficient care must be taken to protect the terminal against static discharges during the installation. Once the unit is installed and connected, these precautions are no longer necessary.

1.1.5 Factory settings

The unit is delivered from factory with certain factory settings. These are based on average values and are not necessarily the correct settings for matching the engine/generator set in question. Precautions must be taken to check the settings before running the engine/generator set.

1.2 About the Parameter List

1.2.1 General purpose of the Parameter List

This document is a complete parameter list including all parameters, which means that some of the option parameters included may not be accessible in the system in question.

The document includes a complete standard alarm list and a complete standard parameter list for setup. Therefore, this document is to be used for reference, when information about specific alarms and parameters is needed.



Please make sure to read this document before starting to work with the unit and the genset to be controlled. Failure to do this could result in human injury or damage to the equipment.

1.2.2 Intended users

This Parameter List is mainly intended for the person responsible for the unit parameter setup. In most cases, this would be a panel builder designer. Naturally, other users might also find useful information here.

1.2.3 Contents and overall structure

This document is divided into chapters, and in order to make the structure simple and easy to use, each chapter will begin from the top of a new page.

2. Alarm list

2.1 General information about the alarm list

2.1.1 Alarm list features and options



In the following, these abbreviations are used:

G: Generator

GB: Generator breaker

MB: Mains breaker

N/A: Not available

This chapter includes a complete alarm list, including all possible options. Therefore, this chapter is to be used for reference when specific information about the individual parameters is needed for the unit setup.

The table consists of the following possible adjustments:

Set point:	The alarm set point is adjusted in the set point menu. The setting is a percentage of the nominal values.
Delay:	The timer setting is the time that must expire from the alarm level is reached until the alarm occurs.
Relay output A:	A relay can be activated by output A.
Relay output B:	A relay can be activated by output B.
Enable:	The alarm can be activated or deactivated. ON means always activated, RUN means that the alarm has run status. This means it is activated when the running signal is present.
Fail class:	When the alarm occurs the unit will react depending on the selected fail class.

Fail classes are:


Fail class	DG (diesel generator)	Mains unit
F1	Block	Block
F2	Warning	Warning
F3	Trip GB	Trip TB
F4	Trip + Stop	Trip MB
F5	Shutdown	N/A
F6	Trip MB	N/A
F7	Safety stop	N/A
F8	Trip MB/GB	N/A



Small differences due to the character of the parameters may exist between the individual tables.

It is also possible to configure the parameters by using the PC utility software. It will be possible to make the same configurations as described above.

By using the PC utility software, extra functionality is available. For all the protections it is possible to make an automatic acknowledgement of the alarm.



The screenshot shows a software window titled "Parameter 'G -P> 1" (Channel 1000)". The window contains several configuration fields and a commissioning section.

- Setpoint :** A slider bar ranging from -50 to 0, with a current value of -5 %.
- Timer :** A slider bar ranging from 0,1 to 100,0, with a current value of 10 sec.
- Fail class :** A dropdown menu set to "Trip of GB".
- Output A :** A dropdown menu set to "Not used".
- Output B :** A dropdown menu set to "Not used".
- Password level :** A dropdown menu set to "Customer".
- Commissioning section:**
 - ☒ Enable
 - ☐ High Alarm
 - ☐ Inverse proportional
 - ☐ Auto acknowledge
 - Inhibits...** (dropdown menu)
 - Actual value : 0 %**
 - Time elapsed : 0 sec (0 %)**
 - A slider bar for time elapsed, ranging from 0 sec to 10 sec.

At the bottom of the window are three buttons: "Write", "OK", and "Cancel".

2.2 Protection parameters

2.2.1 Reverse power and overcurrent protection

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1000 Reverse power 1							
1001	–P> 1	Set point	-200.0 % 0.0 %	-5.0 %		Designer's Reference Handbook	The alarm and fail class are ac- tivated when the reverse power has been continuously above the programmed value during the programmed delay.
1002	–P> 1	Timer	0.1 s 100.0 s	10.0 s			
1003	–P> 1	Relay output A	Not used Option- depend- ent	Not used			
1004	–P> 1	Relay output B	Not used Option- depend- ent	Not used			
1005	–P> 1	Enable	OFF ON	ON			
1006	–P> 1	Fail class	F1...F8	Trip GB (F3)			
1010 Reverse power 2							
1011	–P> 2	Set point	-200.0 % 0.0 %	-5.0 %		Designer's Reference Handbook	The alarm and fail class are ac- tivated when the reverse power has been continuously above the programmed value during the programmed delay.
1012	–P> 2	Timer	0.1 s 100.0 s	10.0 s			
1013	–P> 2	Relay output A	Not used Option- depend- ent	Not used			
1014	–P> 2	Relay output B	Not used Option- depend- ent	Not used			
1015	–P> 2	Enable	OFF ON	ON			
1016	–P> 2	Fail class	F1...F8	Trip GB (F3)			
1030 Overcurrent 1							

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1031	I> 1	Set point	50.0 % 200.0 %	115.0 %		Designer's Reference Handbook	The alarm and fail class are ac- tivated when the current has been continuously above the programmed value during the programmed delay.
1032	I> 1	Timer	0.1 s 3200.0 s	10.0 s			
1033	I> 1	Relay output A	Not used Option- depend- ent	Not used			
1034	I> 1	Relay output B	Not used Option- depend- ent	Not used			
1035	I> 1	Enable	OFF ON	ON			
1036	I> 1	Fail class	F1...F8	Warn- ing(F2)			
1040 Overcurrent 2							
1041	I> 2	Set point	50.0 % 200.0 %	120.0 %		Designer's Reference Handbook	The alarm and fail class are ac- tivated when the current has been continuously above the programmed value during the programmed delay.
1042	I> 2	Timer	0.1 s 3200.0 s	5.0 s			
1043	I> 2	Relay output A	Not used Option- depend- ent	Not used			
1044	I> 2	Relay output B	Not used Option- depend- ent	Not used			
1045	I> 2	Enable	OFF ON	ON			
1046	I> 2	Fail class	F1...F8	Trip GB (F3)			
1050 Overcurrent 3							
1051	I> 3	Set point	50.0 % 200.0 %	115.0 %		Designer's Reference Handbook	The alarm and fail class are ac- tivated when the current has been continuously above the programmed value during the programmed delay.
1052	I> 3	Timer	0.1 s 3200.0 s	10.0 s			
1053	I> 3	Relay output A	Not used Option- depend- ent	Not used			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1054	I> 3	Relay output B	Not used Option- depend- ent	Not used			
1055	I> 3	Enable	OFF ON	ON			
1056	I> 3	Fail class	F1...F8	Trip GB (F3)			
1060 Overcurrent 4							
1061	I> 4	Set point	50.0 % 200.0 %	120.0 %		Designer's Reference Handbook	The alarm and fail class are ac- tivated when the current has been continuously above the programmed value during the programmed delay.
1062	I> 4	Timer	0.1 s 3200.0 s	5.0 s			
1063	I> 4	Relay output A	Not used Option- depend- ent	Not used			
1064	I> 4	Relay output B	Not used Option- depend- ent	Not used			
1065	I> 4	Enable	OFF ON	ON			
1066	I> 4	Fail class	F1...F8	Trip GB (F3)			
1080 I> inverse							
1081	I> in- verse Type	Set point	IEC In- verse Custom	IEC In- verse		Designer's Reference Handbook	Type selections are: IEC Inverse IEC Very Inverse IEC Extremely Inv. IEEE Moderately Inv. IEEE Very Inverse IEEE Extremely Inv. Custom Output B is only available in the utility software.
1082	I> in- verse Limit	Set point	50 % 200 %	110.0 %			
1083	I> in- verse TMS	Set point	0.1 100.0	1.0			
1084	I> in- verse k	Set point	0.001 s 32.000 s	0.140 s			
1085	I> in- verse c	Set point	0.000 s 32.000 s	0.000 s			
1086	I> in- verse a	Set point	0.001 32.000	0.020			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1087	I> in-verse	Relay output A	Not used Option-depend-ent	Not used			
1088	I> in-verse	Enable	OFF ON	ON			
1089	I> in-verse	Fail class	F1...F8	Trip GB (F3)			
1130 Fast overcurrent 1							
1131	I>> 1	Set point	150.0 % 350.0 %	150.0 %		Designer's Reference Handbook	The alarm settings relate to the nominal current setting. The alarm and fail class are activated when the current has been continuously above the programmed value during the programmed delay.
1132	I>> 1	Timer	0.0 s 100.0 s	2.0 s			
1133	I>> 1	Relay output A	Not used Option-depend-ent	Not used			
1134	I>> 1	Relay output B	Not used Option-depend-ent	Not used			
1135	I>> 1	Enable	OFF ON	OFF			
1136	I>> 1	Fail class	F1...F8	Trip GB (F3)			
1140 Fast overcurrent 2							
1141	I>> 2	Set point	150.0 % 350.0 %	200 %		Designer's Reference Handbook	The alarm and fail class are activated when the current has been continuously above the programmed value during the programmed delay
1142	I>> 2	Delay	0.0 s 100.0 s	0.5 s			
1143	I>> 2	Relay output A	Not used Option-depend-ent	Not used			
1144	I>> 2	Relay output B	Not used Option-depend-ent	Not used			
1145	I>> 2	Enable	OFF ON	OFF			
1146	I>> 2	Fail class	F1...F8	Trip GB (F3)			

2.2.2 Voltage protections

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1150 G overvoltage 1							
1151	G U> 1	Set point	100.0 % 120.0 %	103.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the voltage has been continuously above the programmed value during the programmed delay.
1152	G U> 1	Timer	0.1 s 100.0 s	10.0 s			
1153	G U> 1	Relay output A	Not used Option- dep.	Not used			
1154	G U> 1	Relay output B	Not used Option- dep.	Not used			
1155	G U> 1	Enable	OFF ON	OFF			
1156	G U> 1	Fail class	F1...F8	Warning (F2)			
1160 G overvoltage 2							
1161	G U> 2	Set point	100.0 % 120.0 %	105.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the voltage has been continuously above the programmed value during the programmed delay.
1162	G U> 2	Timer	0.1 s 100.0 s	5.0 s			
1163	G U> 2	Relay output A	Not used Option- dep.	Not used			
1164	G U> 2	Relay output B	Not used Option- dep.	Not used			
1165	G U> 2	Enable	OFF ON	OFF			
1166	G U> 2	Fail class	F1...F8	Warning (F2)			
1170 G undervoltage 1							
1171	G U< 1	Set point	40.0 % 100.0 %	97.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the voltage has been continuously under the programmed value during the programmed delay.
1172	G U< 1	Timer	0.1 s 100.0 s	10.0 s			
1173	G U< 1	Relay output A	Not used Option- dep.	Not used			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1174	G U< 1	Relay output B	Not used Option- dep.	Not used			
1175	G U< 1	Enable	OFF ON	OFF			
1176	G U< 1	Fail class	F1...F8	Warning (F2)			
1180 G undervoltage 2							
1181	G U< 2	Set point	40.0 % 100.0 %	95.0 %		Designer's Reference Handbook	The alarm and fail class are acti- vated when the voltage has been continuously under the program- med value during the program- med delay.
1182	G U< 2	Timer	0.1 s 100.0 s	5.0 s			
1183	G U< 2	Relay output A	Not used Option- dep.	Not used			
1184	G U< 2	Relay output B	Not used Option- dep.	Not used			
1185	G U< 2	Enable	OFF ON	OFF			
1186	G U< 2	Fail class	F1...F8	Warning (F2)			
1190 G undervoltage 3							
1191	G U< 3	Set point	40.0 % 100.0 %	95.0 %		Designer's Reference Handbook	The alarm and fail class are acti- vated when the voltage has been continuously under the program- med value during the program- med delay.
1192	G U< 3	Timer	0.1 s 100.0 s	5.0 s			
1193	G U< 3	Relay output A	Not used Option- dep.	Not used			
1194	G U< 3	Relay output B	Not used Option- dep.	Not used			
1195	G U< 3	Enable	OFF ON	OFF			
1196	G U< 3	Fail class	F1...F8	Warning (F2)			

2.2.3 Frequency protections



Frequency settings relate to the nominal frequency setting.

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1210 G overfrequency 1							
1211	G f> 1	Set point	100.0 % 120.0 %	103.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the frequency has been continuously above the programmed value during the programmed delay. Frequency settings relate to nominal frequency setting.
1212	G f> 1	Timer	0.2 s 100.0 s	10.0 s			
1213	G f> 1	Relay output A	Not used Option-dependent	Not used			
1214	G f> 1	Relay output B	Not used Option-dependent	Not used			
1215	G f> 1	Enable	OFF ON	OFF			
1216	G f> 1	Fail class	F1...F8	Warning (F2)			
1220 G overfrequency 2							
1221	G f> 2	Set point	100.0 % 120.0 %	105.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the frequency has been continuously above the programmed value during the programmed delay.
1222	G f> 2	Timer	0.2 s 100.0 s	5.0 s			
1223	G f> 2	Relay output A	Not used Option-dependent	Not used			
1224	G f> 2	Relay output B	Not used Option-dependent	Not used			
1225	G f> 2	Enable	OFF ON	OFF			
1226	G f> 2	Fail class	F1...F8	Warning (F2)			
1230 G overfrequency 3							

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1231	G f> 3	Set point	100.0 % 120.0 %	105.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the frequency has been continuously above the programmed value during the programmed delay.
1232	G f> 3	Timer	0.2 s 100.0 s	5.0 s			
1233	G f> 3	Relay output A	Not used Option- depend- ent	Not used			
1234	G f> 3	Relay output B	Not used Option- depend- ent	Not used			
1235	G f> 3	Enable	OFF ON	OFF			
1236	G f> 3	Fail class	F1...F8	Warning (F2)			
1240 G underfrequency 1							
1241	G f<1	Set point	80.0 % 100.0 %	97.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the frequency has been continuously under the programmed value during the programmed delay.
1242	G f<1	Timer	0.2 s 100.0 s	10.0 s			
1243	G f<1	Relay output A	Not used Option- depend- ent	Not used			
1244	G f<1	Relay output B	Not used Option- depend- ent	Not used			
1245	G f<1	Enable	OFF ON	OFF			
1246	G f<1	Fail class	F1...F8	Warning (F2)			
1250 G underfrequency 2							
1251	G f<2	Set point	80.0 % 100.0 %	95.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the frequency has been continuously under the programmed value during the programmed delay.
1252	G f<2	Timer	0.2 s 100.0 s	5.0 s			
1253	G f<2	Relay output A	Not used Option- depend- ent	Not used			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1254	G f<2	Relay output B	Not used Option- depend- ent	Not used			
1255	G f<2	Enable	OFF ON	OFF			
1256	G f<2	Fail class	F1...F8	Warning (F2)			
1260 G underfrequency 3							
1261	G f<3	Set point	80.0 % 100.0 %	95.0 %		Designer's Reference Handbook	The alarm and fail class are acti- vated when the frequency has been continuously under the pro- grammed value during the pro- grammed delay.
1262	G f<3	Timer	0.2 s 100.0 s	5.0 s			
1263	G f<3	Relay output A	Not used Option- depend- ent	Not used			
1264	G f<3	Relay output B	Not used Option- depend- ent	Not used			
1265	G f<3	Enable	OFF ON	OFF			
1266	G f<3	Fail class	F1...F8	Warning (F2)			

2.2.4 Busbar voltage protections



Voltage settings relate to the nominal voltage setting.

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1270 Busbar overvoltage 1							
1271	BB U> 1	Set point	100.0 % 120.0 %	103.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the voltage has been continuously above the programmed value during the programmed delay.
1272	BB U> 1	Timer	0.00 s 99.99 s	10.00 s			
1273	BB U> 1	Relay output A	Not used Option- depend- ent	Not used			
1274	BB U> 1	Relay output B	Not used Option- depend- ent	Not used			
1275	BB U> 1	Enable	OFF ON	OFF			
1276	BB U> 1	Fail class	F1...F8	Warning (F2)			
1280 Busbar overvoltage 2							
1281	BB U> 2	Set point	100.0 % 120.0 %	105.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the voltage has been continuously above the programmed value during the programmed delay.
1282	BB U> 2	Timer	0.00 s 99.99 s	10.00 s			
1283	BB U> 2	Relay output A	Not used Option- depend- ent	Not used			
1284	BB U> 2	Relay output B	Not used Option- depend- ent	Not used			
1285	BB U> 2	Enable	OFF ON	OFF			
1286	BB U> 2	Fail class	F1...F8	Warning (F2)			
1300 Busbar undervoltage 1							

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1301	BB U< 1	Set point	40.0 % 100.0 %	97.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the voltage has been continuously under the programmed value during the programmed delay.
1302	BB U< 1	Timer	0.00 s 99.99 s	10.00 s			
1303	BB U< 1	Relay output A	Not used Option- depend- ent	Not used			
1304	BB U< 1	Relay output B	Not used Option- depend- ent	Not used			
1305	BB U< 1	Enable	OFF ON	OFF			
1306	BB U< 1	Fail class	F1...F8	Warning (F2)			
1310 Busbar undervoltage 2							
1311	BB U< 2	Set point	40.0 % 100.0 %	95.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the voltage has been continuously under the programmed value during the programmed delay.
1312	BB U< 2	Timer	0.00 s 99.99 s	5.00 s			
1313	BB U< 2	Relay output A	Not used Option- depend- ent	Not used			
1314	BB U< 2	Relay output B	Not used Option- depend- ent	Not used			
1315	BB U< 2	Enable	OFF ON	OFF			
1316	BB U< 2	Fail class	F1...F8	Warning (F2)			

2.2.5 Busbar frequency protections



Frequency settings relate to the nominal frequency setting.

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1350 Busbar overfrequency 1							
1351	BB f> 1	Set point	100.0 % 120.0 %	103.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the frequency has been continuously above the programmed value during the programmed delay.
1352	BB f> 1	Timer	0.00 s 99.99 s	10.00 s			
1353	BB f> 1	Relay output A	Not used Option-dep.	Not used			
1354	BB f> 1	Relay output B	Not used Option-dep.	Not used			
1355	BB f> 1	Enable	OFF ON	OFF			
1356	BB f> 1	Fail class	F1...F8	Warning (F2)			
1360 Busbar overfrequency 2							
1361	BB f> 2	Set point	100.0 % 120.0 %	105.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the frequency has been continuously above the programmed value during the programmed delay.
1362	BB f> 2	Timer	0.00 s 99.99 s	5.00 s			
1363	BB f> 2	Relay output A	Not used Option-dep.	Not used			
1364	BB f> 2	Relay output B	Not used Option-dep.	Not used			
1365	BB f> 2	Enable	OFF ON	OFF			
1366	BB f> 2	Fail class	F1...F8	Warning (F2)			
1380 Busbar underfrequency 1							
1381	BB f< 1	Set point	80.0 % 100.0 %	97.0 %		Designer's Reference Handbook	The alarm and fail class are activated when the frequency has been continuously under the programmed value during the programmed delay.
1382	BB f< 1	Timer	0.00 s 99.99 s	10.00 s			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1383	BB f< 1	Relay output A	Not used Option- dep.	Not used			
1384	BB f< 1	Relay output B	Not used Option- dep.	Not used			
1385	BB f< 1	Enable	OFF ON	OFF			
1386	BB f< 1	Fail class	F1...F8	Warning (F2)			
1390 Busbar underfrequency 2							
1391	BB f< 2	Set point	80.0 % 100.0 %	95.0 %		Designer's Reference Handbook	The alarm and fail class are acti- vated when the frequency has been continuously under the pro- grammed value during the pro- grammed delay.
1392	BB f< 2	Timer	0.00 s 99.99 s	5.00 s			
1393	BB f< 2	Relay output A	Not used Option- dep.	Not used			
1394	BB f< 2	Relay output B	Not used Option- dep.	Not used			
1395	BB f< 2	Enable	OFF ON	OFF			
1396	BB f< 2	Fail class	F1...F8	Warning (F2)			

2.2.6 Overload protections

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1450 Overload 1							
1451	P> 1	Set point	-200.0 % 200.0 %	100.0 %		Designer's Reference Handbook	Settings relate to nominal power. The alarm and fail class are activa- ted when the power has been contin- uously above the programmed value during the programmed de- lay.
1452	P> 1	Timer	0.1 s 3200.0 s	10.0 s			
1453	P> 1	Relay output A	Not used Option- dep.	Not used			
1454	P> 1	Relay output B	Not used Option- dep.	Not used			
1455	P> 1	Enable	OFF ON	OFF			
1456	P> 1	Fail class	F1...F8	Warn- ing (F2)			
1460 Overload 2							
1461	P> 2	Set point	-200.0 % 200.0 %	110.0 %		Designer's Reference Handbook	The alarm and fail class are activa- ted when the power has been contin- uously above the programmed value during the programmed de- lay.
1462	P> 2	Timer	0.1 s 3200.0 s	5.0 s			
1463	P> 2	Relay output A	Not used Option- dep.	Not used			
1464	P> 2	Relay output B	Not used Option- dep.	Not used			
1465	P> 2	Enable	OFF ON	OFF			
1466	P> 2	Fail class	F1...F8	Trip GB (F3)			
1470 Overload 3							
1471	P> 3	Set point	-200.0 % 200.0 %	100.0 %		Designer's Reference Handbook	The alarm and fail class are activa- ted when the power has been contin- uously above the programmed value during the programmed de- lay.
1472	P> 3	Timer	0.1 s 3200.0 s	10.0 s			
1473	P> 3	Relay output A	Not used Option- dep.	Not used			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1474	P> 3	Relay output B	Not used Option- dep.	Not used			
1475	P> 3	Enable	OFF ON	OFF			
1476	P> 3	Fail class	F1...F8	Trilp GB (F3)			
1480 Overload 4							
1481	P> 4	Set point	-200.0 % 200.0 %	110.0 %		Designer's Reference Handbook	The alarm and fail class are activa- ted when the power has been con- tinuously above the programmed value during the programmed de- lay.
1482	P> 4	Timer	0.1 s 3200.0 s	5.0 s			
1483	P> 4	Relay output A	Not used Option- dep.	Not used			
1484	P> 4	Relay output B	Not used Option- dep.	Not used			
1485	P> 4	Enable	OFF ON	OFF			
1486	P> 4	Fail class	F1...F8	Trip GB (F3)			
1490 Overload 5							
1491	P> 5	Set point	-200.0 % 200.0 %	100.0 %		Designer's Reference Handbook	The alarm and fail class are activa- ted when the power has been con- tinuously above the programmed value during the programmed de- lay.
1492	P> 5	Timer	0.1 s 3200.0 s	10.0 s			
1493	P> 5	Relay output A	Not used Option- dep.	Not used			
1494	P> 5	Relay output B	Not used Option- dep.	Not used			
1495	P> 5	Enable	OFF ON	OFF			
1496	P> 5	Fail class	F1...F8	Trip GB (F3)			

2.2.7 Undervoltage and reactive power low

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1960 U and Q < 1							
1961	U and Q < 1	Set point	40.0 % 100.0 %	85.0 %		Option A1	The setting relates to the genera- tor nominal voltage. The condition for trip is that the ac- tual voltage drops below the set- ting value and the reactive power is ≤ 0 kVAr.
1962	U and Q < 1	Timer	0.1 s 3200.0 s	0.5 s			
1963	U and Q < 1	Relay output A	Option- dep.	Not used			
1964	U and Q < 1	Relay output B	Option- dep.	Not used			
1965	U and Q < 1	Enable	OFF ON	OFF			
1966	U and Q < 1	Fail class	F1...F8	Warning (F2)			
1970 U and Q < 2							
1971	U and Q < 2	Set point	40.0 % 100.0 %	85.0 %		Option A1	The setting relates to the genera- tor nominal voltage. The condition for trip is that the ac- tual voltage drops below the set- ting value and the reactive power is ≤ 0 kVAr.
1972	U and Q < 2	Timer	0.1 s 3200.0 s	0.5 s			
1973	U and Q < 2	Relay output A	Option- dep.	Not used			
1974	U and Q < 2	Relay output B	Option- dep.	Not used			
1975	U and Q < 2	Enable	OFF ON	OFF			
1976	U and Q < 2	Fail class	F1...F8	Warning (F2)			
1980 GB/MB external trip							
1981	GB ext. trip	Enable	OFF ON	ON		Design- er's Refer- ence Handbook	The generator breaker or the mains breaker has been tripped by an external device.
1982	GB ext. trip	Fail class	F1...F8	Warning (F2)			
1983	MB ext. trip	Enable	OFF ON	ON			
1984	MB ext. trip	Fail class	F1...F8	Warning (F2)			

Minimum current and minimum Phi angle

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
1990 U and Q< 1							
1991	I Min. 1	Set point	0 % 20 %	0 %		Option A1	Settings relate to U and Q< parameters 1960 and 1970. Condition for "U and Q<" trip is that the current exceeds the I Min. set point. Min. Phi angle expands the tripping window.
1992	Angle 1	Set point	0 ° 6 °	0 °			
1990 U and Q< 2							
1993	I Min. 2	Set point	0 % 20 %	0 %		Option A1	Settings relate to U and Q< parameters 1960 and 1970. Condition for "U and Q<" trip is that the current exceeds the I Min. set point. Min. Phi angle expands the tripping window.
1994	Angle 2	Set point	0 ° 6 °	0 °			

2.3 Breaker control parameters

2.3.1 Breaker alarms

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
2110 Sync. blackout							
2111	Sync. blackout	dfMax.	0.0 Hz 5.0 Hz	3.0 Hz		Designer's Reference Handbook	Settings are accepted limits for closing of the breaker, referring to nominal frequency and voltage.
2112	Sync. blackout	dUMax.	2 % 10 %	5 %			
2150 Phase sequence error							
2151	Phase seq er- ror	Relay output A	Not used Option- dep.	Not used		Designer's Reference Handbook	Prior to closing a breaker, the unit checks that the phase sequence is correct, depending on the chosen phase direction in parameter 2154: "Phase rotation". If it is incorrect (reversed), an alarm will be issued and the breaker in question will not be closed.
2152	Phase seq er- ror	Relay output B	Not used Option- dep.	Not used			
2153	Phase seq er- ror	Fail class	F1...F8	Block (F1)			
2154	Phase rotation	Set point	L1L2L3 L1L3L2	L1L2L3			
2160 GB open failure							
2161	GB open fail	Timer	1.0 s 10.0 s	2.0 s		Designer's Reference Handbook	The breaker open failure will occur if the unit has transmitted a breaker open signal and the breaker feedback has not changed position from ON to OFF within the time delay.
2162	GB open fail	Relay output A	Not used Option- dep.	Not used			
2163	GB open fail	Relay output B	Not used Option- dep.	Not used			
2164	GB open fail	Enable	OFF ON	ON			
2165	GB open fail	Fail class	F1...F8	Warning (F2)			
2170 GB breaker close failure							
2171	GB close fail	Timer	1.0 s 5.0 s	2.0 s		Designer's Reference Handbook	The breaker close failure will occur if the unit has transmitted a breaker close signal and the breaker feedback has not changed position from OFF to ON within the time delay.
2172	GB close fail	Relay output A	Not used Option- dep.	Not used			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
2173	GB close fail	Relay output B	Not used Option- dep.	Not used			
2174	GB close fail	Enable	OFF ON	ON			
2175	GB close fail	Fail class	F1...F8	Warning (F2)			
2180 GB breaker position failure							
2181	GB pos fail	Timer	1.0 s 5.0 s	1.0 s		Designer's Reference Handbook	This alarm will occur if the breaker feedbacks for ON and OFF are both missing or active for more than the time delay.
2182	GB pos fail	Relay output A	Not used Option- dep.	Not used			
2183	GB pos fail	Relay output B	Not used Option- dep.	Not used			
2184	GB pos fail	Enable	OFF ON	ON			
2185	GB pos fail	Fail class	F1...F8	Warning (F2)			
2200 MB open failure							
2201	MB open fail	Timer	1.0 s 10.0 s	2.0 s		Designer's Reference Handbook	The breaker open failure will occur if the unit has transmit- ted a breaker open signal and the breaker feedback has not changed position from ON to OFF within the time delay.
2202	MB open fail	Relay output A	Not used Option- dep.	Not used			
2203	MB open fail	Relay output B	Not used Option- dep.	Not used			
2204	MB open fail	Enable	OFF ON	ON			
2205	MB open fail	Fail class	F1...F8	Warning (F2)			
2210 MB close failure							
2211	MB close fail	Timer	1.0 s 5.0 s	2.0 s		Designer's Reference Handbook	The breaker close failure will occur if the unit has transmit- ted a breaker close signal and the breaker feedback has not changed position from OFF to ON within the time delay.
2212	MB close fail	Relay output A	Not used Option- dep.	Not used			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
2213	MB close fail	Relay output B	Not used Option-dep.	Not used			
2214	MB close fail	Enable	OFF ON	ON			
2215	MB close fail	Fail class	F1...F8	Warning (F2)			
2220 MB position failure							
2221	MB pos fail	Timer	1.0 s 5.0 s	1.0 s		Designer's Reference Handbook	This alarm will occur if the breaker feedbacks for ON and OFF are both missing or active for more than the time delay.
2222	MB pos fail	Relay output A	Not used Option-dep.	Not used			
2223	MB pos fail	Relay output B	Not used Option-dep.	Not used			
2224	MB pos fail	Enable	OFF ON	ON			
2225	MB pos fail	Fail class	F1...F8	Warning (F2)			

No.	Setting		Min. setting	Max. setting	Factory setting
2770 EIC control					
2771	EIC control	Droop	0.0 %	25.0 %	0.0 %
2772	EIC control	Scania rpm	User 1500 rpm 1800 rpm Low Idle		User
2773	EIC control	Cummins gain	0.00	10.00	5.00
2790 EIC speed demand switch					
2791	EIC speed demand switch	Local normal sw.	Analogue CAN UpDown ECU UpDown CAN Analogue ECU Analogue ECU relative Frequency		Analogue CAN
2792	EIC speed demand switch	Local emergency sw.			
2793	EIC speed demand switch	Remote normal sw.			
2794	EIC speed demand switch	Remote emergency sw.			

2.4 Input/output parameters, binary input setup

2.4.1 Digital input 10-15 and 56-57 setup

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
3000 Digital input 10							
3001	Dig. input 10	Timer	0.0 s 100.0 s	10.0 s		Designer's Reference Handbook	The input is configurable and can have different functions in different units.
3002	Dig. input 10	Relay output A	Not used Option-dep.	Not used			
3003	Dig. input 10	Relay output B	Not used Option-dep.	Not used			
3004	Dig. input 10	Enable	OFF ON	OFF			
3005	Dig. input 10	Fail class	F1...F8	Warning (F2)			
3006	Dig. input 10	High Alarm	OFF ON	ON			



The same settings apply to inputs 11-15 and 56-57, minus 3010 to 3070.

2.4.2 Digital input 6-8 setup

No.	Setting		Min. Max.	Facto- ry set- ting	Notes	Ref.	Description
3400 Digital input 6							
3401	Wire fail 6	Enable	OFF	OFF		Designer's Reference Handbook	The input is configurable and can have different functions in different units. (Only available if multi-input 6 is configured to "binary" in menu 10980).
3402	Dig. input 6	Timer	0.0 s 100.0 s	10.0 s			
3403	Dig. input 6	Relay output A	Not used Option-dep.	Not used			
3404	Dig. input 6	Relay output B	Not used Option-dep.	Not used			
3405	Dig. input 6	Enable	OFF ON	OFF			
3406	Dig. input 6	Fail class	F1...F8	Warn- ing (F2)			
3410 Digital input 7							
3411	Wire fail 7	Enable	OFF	OFF		Designer's Reference Handbook	The input is configurable and can have different functions in different units. (Only available if multi-input 7 is configured to "binary" in menu 10990).
3412	Dig. input 7	Timer	0.0 s 100.0 s	10.0 s			
3413	Dig. input 7	Relay output A	Not used Option-dep.	Not used			
3414	Dig. input 7	Relay output B	Not used Option-dep.	Not used			
3415	Dig. input 7	Enable	OFF ON	OFF			
3416	Dig. input 7	Fail class	F1...F8	Warn- ing (F2)			
3420 Digital input 8							

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
3421	Wire fail 8	Enable	OFF	OFF		Designer's Reference Handbook	The input is configurable and can have different functions in different units. (Only available if multi-input 8 is configured to "binary" in menu 11000).
3422	Dig. input 8	Timer	0.0 s 100.0 s	10.0 s			
3423	Dig. input 8	Relay output A	Not used Option-dep.	Not used			
3424	Dig. input 8	Relay output B	Not used Option-dep.	Not used			
3425	Dig. input 8	Enable	OFF ON	OFF			
3426	Dig. input 8	Fail class	F1...F8	Warning (F2)			

2.4.3 Emergency stop

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
3490 Emergency stop							
3491	Emer. stop	Timer	0.0 s 60.0 s	0.0 s		Designer's Reference Handbook	Emergency stop input is intended for a normally closed contact.
3492	Emer. stop	Relay output A	Not used Option- dependent	Not used			
3493	Emer. stop	Relay output B	Not used Option-de- pendent	Not used			
3494	Emer. stop	Enable	OFF ON	ON			
3495	Emer. stop	Fail class	F1...F8	Shut- down (F5)			

2.4.4 M-Logic alarm 1-5 setup

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
3570 Mlogic alarm 1							
3570	Mlogic alarm 1	Timer	0.0 s 100.0 s	10.0 s			The input is configura- ble.
3571	Mlogic alarm 1	Relay output A	Not used Option-dep.	Not used			
3572	Mlogic alarm 1	Relay output B	Not used Option-dep.	Not used			
3573	Mlogic alarm 1	Enable	OFF ON	OFF			
3574	Mlogic alarm 1	Fail class	F1...F8	Warning (F2)			
3575	Mlogic alarm 1	High alarm	OFF ON	ON			



The same settings apply to alarm inputs 2-5, menus 3580 to 3610.

2.5 Analogue input setup

2.5.1 Multi-input no. 6



The available menus for multi-input no. 6 depend on the input type configured in the PC utility software (menu 10980).

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4120 4-20 mA 6.1							
4121	4-20 mA 6.1	Set point	4 mA 20 mA	10 mA		Designer's Reference Handbook	The multi-input 6 has been configured as '4-20 mA'.
4122	4-20 mA 6.1	Timer	0.0 s 999.0 s	120.0 s			
4123	4-20 mA 6.1	Relay output A	Not used Option- dep.	Not used			
4124	4-20 mA 6.1	Relay output B	Not used Option- dep.	Not used			
4125	4-20 mA 6.1	Enable	OFF ON	OFF			
4126	4-20 mA 6.1	Fail class	F1...F8	Warning (F2)			
4130 4-20 mA 6.2							
4131	4-20 mA 6.2	Set point	4 mA 20 mA	10 mA		Designer's Reference Handbook	The multi-input 6 has been configured as '4-20 mA'.
4132	4-20 mA 6.2	Timer	0.0 s 999.0 s	120.0 s			
4133	4-20 mA 6.2	Relay output A	Not used Option- dep.	Not used			
4134	4-20 mA 6.2	Relay output B	Not used Option- dep.	Not used			
4135	4-20 mA 6.2	Enable	OFF ON	OFF			
4136	4-20 mA 6.2	Fail class	F1...F8	Warning (F2)			
4160 Pt100/Pt1000 6.1							
4161	PT 6.1	Set point	-49 482	80		Designer's Reference Handbook	The multi-input 6 has been configured as 'Pt100' or 'Pt1000'.
4162	PT 6.1	Timer	0.0 s 999.0 s	5.0 s			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4163	PT 6.1	Relay output A	Not used Option- dep.	Not used			Pt100/Pt1000 set point can be in deg. C or F, dependent on the unit selection (menu 10970).
4164	PT 6.1	Relay output B	Not used Option- dep.	Not used			
4165	PT 6.1	Enable	OFF ON	OFF			
4166	PT 6.1	Fail class	F1...F8	Warning (F2)			
4167	PT 6.1	Offset	0.0 Ohm 5.0 Ohm	0.0 Ohm			
4170 Pt100/Pt1000 6.2							
4171	PT 6.2	Set point	-49 482	80		Designer's Reference Handbook	The multi-input 6 has been configured as 'Pt100' or 'Pt1000'. Pt100/Pt1000 set point can be in deg. C or F, dependent on the unit selection (menu 10970).
4172	PT 6.2	Timer	0.0 s 999.0 s	10.0 s			
4173	PT 6.2	Relay output A	Not used Option- dep.	Not used			
4174	PT 6.2	Relay output B	Not used Option- dep.	Not used			
4175	PT 6.2	Enable	OFF ON	OFF			
4176	PT 6.2	Fail class	F1...F8	Warning (F2)			
4180 Resistance measurement input, oil pressure 6.1							
4181	RMI oil 6.1	Set point	0.0 145.0	2.0		Designer's Reference Handbook	The multi-input 6 has been configured as 'RMI oil pres- sure'. Oil pressure set point can be in Bar or PSI, dependent on the unit selection (menu 10970).
4182	RMI oil 6.1	Timer	0.0 s 999.0 s	5.0 s			
4183	RMI oil 6.1	Relay output A	Not used Option- dep.	Not used			
4184	RMI oil 6.1	Relay output B	Not used Option- dep.	Not used			
4185	RMI oil 6.1	Enable	OFF ON	OFF			
4186	RMI oil 6.1	Fail class	F1...F8	Warning (F2)			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4190 Resistance measurement input, oil pressure 6.2							
4191	RMI oil 6.2	Set point	0.0 145.0	1.0		Designer's Reference Handbook	The multi-input 6 has been configured as 'RMI oil pres- sure'. Oil pressure set point can be in Bar or PSI, dependent on the unit selection (menu 10970).
4192	RMI oil 6.2	Timer	0.0 s 999.0 s	5.0 s			
4193	RMI oil 6.2	Relay output A	Not used Option- dep.	Not used			
4194	RMI oil 6.2	Relay output B	Not used Option- dep.	Not used			
4195	RMI oil 6.2	Enable	OFF ON	OFF			
4196	RMI oil 6.2	Fail class	F1...F8	Shut- down (F5)			
4200 Resistance measurement input, water temperature 6.1							
4201	RMI water 6.1	Set point	-49 482	100		Designer's Reference Handbook	The multi-input 6 has been configured as 'RMI water tem- perature'. Water temperature set point can be in deg. C or F, depend- ent on the unit selection (menu 10970).
4202	RMI water 6.1	Timer	0.0 s 999.0 s	5.0 s			
4203	RMI water 6.1	Relay output A	Not used Option- dep.	Not used			
4204	RMI water 6.1	Relay output B	Not used Option- dep.	Not used			
4205	RMI water 6.1	Enable	OFF ON	OFF			
4206	RMI water 6.1	Fail class	F1...F8	Warning (F2)			
4210 Resistance measurement input, water temperature 6.2							
4211	RMI water 6.2	Set point	-49 482	110		Designer's Reference Handbook	The multi-input 6 has been configured as 'RMI water tem- perature'. Water temperature set point can be in deg. C or F, depend- ent on the unit selection (menu 10970).
4212	RMI water 6.2	Timer	0.0 s 999.0 s	5.0 s			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4213	RMI water 6.2	Relay output A	Not used Option- dep.	Not used			
4214	RMI water 6.2	Relay output B	Not used Option- dep.	Not used			
4215	RMI water 6.2	Enable	OFF ON	OFF			
4216	RMI water 6.2	Fail class	F1...F8	Trip + Stop (F4)			
4220 Resistance measurement input, fuel level 6.1							
4221	RMI fuel 6.1	Set point	0 % 100 %	10 %		Designer's Reference Handbook	The multi-input 6 has been configured as 'RMI fuel level'.
4222	RMI fuel 6.1	Timer	0.0 s 999.0 s	10.0 s			
4223	RMI fuel 6.1	Relay output A	Not used Option- dep.	Not used			
4224	RMI fuel 6.1	Relay output B	Not used Option- dep.	Not used			
4225	RMI fuel 6.1	Enable	OFF ON	OFF			
4226	RMI fuel 6.1	Fail class	F1...F8	Warning (F2)			
4230 Resistance measurement input, fuel level 6.2							
4231	RMI fuel 6.2	Set point	0 % 100 %	5 %		Designer's Reference Handbook	The multi-input 6 has been configured as 'RMI fuel level'.
4232	RMI fuel 6.2	Timer	0.0 s 999.0 s	10.0 s			
4233	RMI fuel 6.2	Relay output A	Not used Option- dep.	Not used			
4234	RMI fuel 6.2	Relay output B	Not used Option- dep.	Not used			
4235	RMI fuel 6.2	Enable	OFF ON	OFF			
4236	RMI fuel 6.2	Fail class	F1...F8	Warning (F2)			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4240 Wire fail 6							
4241	W. fail 6	Relay output A	Not used Option- dep.	Not used		Designer's Reference Handbook	The wire break fault detection is activated.
4242	W. fail 6	Relay output B	Not used Option- dep.	Not used			
4243	W. fail 6	Enable	OFF ON	OFF			
4244	W. fail 6	Fail class	F1...F8	Warning (F2)			

2.5.2 Multi-input no. 7



The available menus for multi-input no. 7 depend on the input type configured in the PC utility software (menu 10990).

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4250 4-20 mA 7.1							
4251	4-20 mA 7.1	Set point	4 mA 20 mA	10 mA		Designer's Reference Handbook	The multi-input 7 has been configured as '4-20 mA'.
4252	4-20 mA 7.1	Timer	0.0 s 999.0 s	120.0 s			
4253	4-20 mA 7.1	Relay output A	Not used Option- dep.	Not used			
4254	4-20 mA 7.1	Relay output B	Not used Option- dep.	Not used			
4255	4-20 mA 7.1	Enable	OFF ON	OFF			
4256	4-20 mA 7.1	Fail class	F1...F8	Warning (F2)			
4260 4-20 mA 7.2							
4261	4-20 mA 7.2	Set point	4 mA 20 mA	10 mA		Designer's Reference Handbook	The multi-input 7 has been configured as '4-20 mA'.
4262	4-20 mA 7.2	Timer	0.0 s 999.0 s	120.0 s			
4263	4-20 mA 7.2	Relay output A	Not used Option- dep.	Not used			
4264	4-20 mA 7.2	Relay output B	Not used Option- dep.	Not used			
4265	4-20 mA 7.2	Enable	OFF ON	OFF			
4266	4-20 mA 7.2	Fail class	F1...F8	Warning (F2)			
4290 Pt100/Pt1000 7.1							
4291	PT 7.1	Set point	-49 482	80		Designer's Reference Handbook	The multi-input 7 has been configured as 'Pt100' or 'Pt1000'.
4292	PT 7.1	Timer	0.0 s 999.0 s	5.0 s			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4293	PT 7.1	Relay output A	Not used Option- dep.	Not used			Pt100/Pt1000 set point can be in deg. C or F, dependent on the unit selection (menu 10970).
4294	PT 7.1	Relay output B	Not used Option- dep.	Not used			
4295	PT 7.1	Enable	OFF ON	OFF			
4296	PT 7.1	Fail class	F1...F8	Warning (F2)			
4297	PT 7.1	Offset	0.0 Ohm 5.0 Ohm	0.0 Ohm			
4300 Pt100/Pt1000 7.2							
4301	PT 7.2	Set point	-49 482	80		Designer's Reference Handbook	The multi-input 7 has been configured as 'Pt100' or 'Pt1000'. Pt100/Pt1000 set point can be in deg. C or F, dependent on the unit selection (menu 10970).
4302	PT 7.2	Timer	0.0 s 999.0 s	10.0 s			
4303	PT 7.2	Relay output A	Not used Option- dep.	Not used			
4304	PT 7.2	Relay output B	Not used Option- dep.	Not used			
4305	PT 7.2	Enable	OFF ON	OFF			
4306	PT 7.2	Fail class	F1...F8	Warning (F2)			
4310 Resistance measurement input, oil pressure 7.1							
4311	RMI oil 7.1	Set point	0.0 145.0	2.0		Designer's Reference Handbook	The multi-input 7 has been configured as 'RMI oil pres- sure'. Oil pressure set point can be in Bar or PSI, dependent on the unit selection (menu 10970).
4312	RMI oil 7.1	Timer	0.0 s 999.0 s	5.0 s			
4313	RMI oil 7.1	Relay output A	Not used Option- dep.	Not used			
4314	RMI oil 7.1	Relay output B	Not used Option- dep.	Not used			
4315	RMI oil 7.1	Enable	OFF ON	OFF			
4316	RMI oil 7.1	Fail class	F1...F8	Warning (F2)			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4320 Resistance measurement input, oil pressure 7.2							
4321	RMI oil 7.2	Set point	0.0 145.0	1.0		Designer's Reference Handbook	The multi-input 7 has been configured as 'RMI oil pres- sure'. Oil pressure set point can be in Bar or PSI, dependent on the unit selection (menu 10970).
4322	RMI oil 7.2	Timer	0.0 s 999.0 s	5.0 s			
4323	RMI oil 7.2	Relay output A	Not used Option- dep.	Not used			
4324	RMI oil 7.2	Relay output B	Not used Option- dep.	Not used			
4325	RMI oil 7.2	Enable	OFF ON	OFF			
4326	RMI oil 7.2	Fail class	F1...F8	Shut- down (F5)			
4330 Resistance measurement input, water temperature 7.1							
4331	RMI water 7.1	Set point	-49 482	100		Designer's Reference Handbook	The multi-input 7 has been configured as 'RMI water tem- perature'. Water temperature set point can be in deg. C or F, depend- ent on the unit selection (menu 10970).
4332	RMI water 7.1	Timer	0.0 s 999.0 s	5.0 s			
4333	RMI water 7.1	Relay output A	Not used Option- dep.	Not used			
4334	RMI water 7.1	Relay output B	Not used Option- dep.	Not used			
4335	RMI water 7.1	Enable	OFF ON	OFF			
4336	RMI water 7.1	Fail class	F1...F8	Warning (F2)			
4340 Resistance measurement input, water temperature 7.2							
4341	RMI water 7.2	Set point	-49 482	110		Designer's Reference Handbook	The multi-input 7 has been configured as 'RMI water tem- perature'. Water temperature set point can be in deg. C or F, depend- ent on the unit selection (menu 10970).
4342	RMI water 7.2	Timer	0.0 s 999.0 s	5.0 s			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4343	RMI water 7.2	Relay output A	Not used Option- dep.	Not used			
4344	RMI water 7.2	Relay output B	Not used Option- dep.	Not used			
4345	RMI water 7.2	Enable	OFF ON	OFF			
4346	RMI water 7.2	Fail class	F1...F8	Trip + Stop (F4)			
4350 Resistance measurement input, fuel level 7.1							
4351	RMI fuel 7.1	Set point	0 % 100 %	10 %		Designer's Reference Handbook	The multi-input 7 has been configured as 'RMI fuel level'.
4352	RMI fuel 7.1	Timer	0.0 s 999.0 s	10.0 s			
4353	RMI fuel 7.1	Relay output A	Not used Option- dep.	Not used			
4354	RMI fuel 7.1	Relay output B	Not used Option- dep.	Not used			
4555	RMI fuel 7.1	Enable	OFF ON	OFF			
4356	RMI fuel 7.1	Fail class	F1...F8	Warning (F2)			
4360 Resistance measurement input, fuel level 7.2							
4361	RMI fuel 7.2	Set point	0 % 100 %	5 %		Designer's Reference Handbook	The multi-input 7 has been configured as 'RMI fuel level'.
4362	RMI fuel 7.2	Timer	0.0 s 999.0 s	10.0 s			
4363	RMI fuel 7.2	Relay output A	Not used Option- dep.	Not used			
4364	RMI fuel 7.2	Relay output B	Not used Option- dep.	Not used			
4365	RMI fuel 7.2	Enable	OFF ON	OFF			
4366	RMI fuel 7.2	Fail class	F1...F8	Warning (F2)			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4370 Wire fail 7							
4371	W. fail 7	Relay output A	Not used Option- dep.	Not used		Designer's Reference Handbook	The wire break fault detection is activated.
4372	W. fail 7	Relay output B	Not used Option- dep.	Not used			
4373	W. fail 7	Enable	OFF ON	OFF			
4374	W. fail 7	Fail class	F1...F8	Warning (F2)			

2.5.3 Multi-input no. 8



The available menus for multi-input no. 8 depend on the input type configured in the PC utility software (menu 11000).

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4380 4-20 mA 8.1							
4381	4-20 mA 8.1	Set point	4 mA 20 mA	10 mA		Designer's Reference Handbook	The multi-input 8 has been configured as '4-20 mA'.
4382	4-20 mA 8.1	Timer	0.0 s 999.0 s	120.0 s			
4383	4-20 mA 8.1	Relay output A	Not used Option- dep.	Not used			
4384	4-20 mA 8.1	Relay output B	Not used Option- dep.	Not used			
4385	4-20 mA 8.1	Enable	OFF ON	OFF			
4386	4-20 mA 8.1	Fail class	F1...F8	Warning (F2)			
4390 4-20 mA 8.2							
4391	4-20 mA 8.2	Set point	4 mA 20 mA	10 mA		Designer's Reference Handbook	The multi-input 8 has been configured as '4-20 mA'.
4392	4-20 mA 8.2	Timer	0.0 s 999.0 s	120.0 s			
4393	4-20 mA 8.2	Relay output A	Not used Option- dep.	Not used			
4394	4-20 mA 8.2	Relay output B	Not used Option- dep.	Not used			
4395	4-20 mA 8.2	Enable	OFF ON	OFF			
4396	4-20 mA 8.2	Fail class	F1...F8	Warning (F2)			
4420 Pt100/Pt1000 8.1							
4421	PT 8.1	Set point	-49 482	80		Designer's Reference Handbook	The multi-input 8 has been configured as 'Pt100' or 'Pt1000'.
4422	PT 8.1	Timer	0.0 s 999.0 s	5.0 s			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4423	PT 8.1	Relay output A	Not used Option- dep.	Not used			Pt100/Pt1000 set point can be in deg. C or F, dependent on the unit selection (menu 10970).
4424	PT 8.1	Relay output B	Not used Option- dep.	Not used			
4425	PT 8.1	Enable	OFF ON	OFF			
4426	PT 8.1	Fail class	F1...F8	Warning (F2)			
4427	PT 8.1	Offset	0.0 Ohm 5.0 Ohm	0.0 Ohm			
4430 Pt100/Pt1000 8.2							
4431	PT 8.2	Set point	-49 482	80		Designer's Reference Handbook	The multi-input 8 has been configured as 'Pt100' or 'Pt1000'. Pt100/Pt1000 set point can be in deg. C or F, dependent on the unit selection (menu 10970).
4432	PT 8.2	Timer	0.0 s 999.0 s	10.0 s			
4433	PT 8.2	Relay output A	Not used Option- dep.	Not used			
4434	PT 8.2	Relay output B	Not used Option- dep.	Not used			
4435	PT 8.2	Enable	OFF ON	OFF			
4436	PT 8.2	Fail class	F1...F8	Warning (F2)			
4440 Resistance measurement input, oil pressure 8.1							
4441	RMI oil 8.1	Set point	0.0 145.0	2.0		Designer's Reference Handbook	The multi-input 8 has been configured as 'RMI oil pressure'. Oil pressure set point can be in Bar or PSI, dependent on the unit selection (menu 10970).
4442	RMI oil 8.1	Timer	0.0 s 999.0 s	5.0 s			
4443	RMI oil 8.1	Relay output A	Not used Option- dep.	Not used			
4444	RMI oil 8.1	Relay output B	Not used Option- dep.	Not used			
4445	RMI oil 8.1	Enable	OFF ON	OFF			
4446	RMI oil 8.1	Fail class	F1...F8	Warning (F2)			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4450 Resistance measurement input, oil pressure 8.2							
4451	RMI oil 8.2	Set point	0.0 145.0	1.0		Designer's Reference Handbook	The multi-input 8 has been configured as 'RMI oil pres- sure'. Oil pressure set point can be in Bar or PSI, dependent on the unit selection (menu 10970).
4452	RMI oil 8.2	Timer	0.0 s 999.0 s	5.0 s			
4453	RMI oil 8.2	Relay output A	Not used Option- dep.	Not used			
4454	RMI oil 8.2	Relay output B	Not used Option- dep.	Not used			
4455	RMI oil 8.2	Enable	OFF ON	OFF			
4456	RMI oil 8.2	Fail class	F1...F8	Shut- down (F5)			
4460 Resistance measurement input, water temperature 8.1							
4461	RMI water 8.1	Set point	-49 482	100		Designer's Reference Handbook	The multi-input 8 has been configured as 'RMI water tem- perature'. Water temperature set point can be in deg. C or F, depend- ent on the unit selection (menu 10970).
4462	RMI water 8.1	Timer	0.0 s 999.0 s	5.0 s			
4463	RMI water 8.1	Relay output A	Not used Option- dep.	Not used			
4464	RMI water 8.1	Relay output B	Not used Option- dep.	Not used			
4465	RMI water 8.1	Enable	OFF ON	OFF			
4466	RMI water 8.1	Fail class	F1...F8	Warning (F2)			
4470 Resistance measurement input, water temperature 8.2							
4471	RMI water 8.2	Set point	-49 482	110		Designer's Reference Handbook	The multi-input 8 has been configured as 'RMI water tem- perature'. Water temperature set point can be in deg. C or F, depend- ent on the unit selection (menu 10970).
4472	RMI water 8.2	Timer	0.0 s 999.0 s	5.0 s			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4473	RMI water 8.2	Relay output A	Not used Option- dep.	Not used			
4474	RMI water 8.2	Relay output B	Not used Option- dep.	Not used			
4475	RMI water 8.2	Enable	OFF ON	OFF			
4476	RMI water 8.2	Fail class	F1...F8	Trip + Stop (F4)			
4480 Resistance measurement input, fuel level 8.1							
4481	RMI fuel 8.1	Set point	0 % 100 %	10 %		Designer's Reference Handbook	The multi-input 8 has been configured as 'RMI fuel level'.
4482	RMI fuel 8.1	Timer	0.0 s 999.0 s	10.0 s			
4483	RMI fuel 8.1	Relay output A	Not used Option- dep.	Not used			
4484	RMI fuel 8.1	Relay output B	Not used Option- dep.	Not used			
4485	RMI fuel 8.1	Enable	OFF ON	OFF			
4486	RMI fuel 8.1	Fail class	F1...F8	Warning (F2)			
4490 Resistance measurement input, fuel level 8.2							
4491	RMI fuel 8.2	Set point	0 % 100 %	5 %		Designer's Reference Handbook	The multi-input 8 has been configured as 'RMI fuel level'.
4492	RMI fuel 8.2	Timer	0.0 s 999.0 s	10.0 s			
4493	RMI fuel 8.2	Relay output A	Not used Option- dep.	Not used			
4494	RMI fuel 8.2	Relay output B	Not used Option- dep.	Not used			
4495	RMI fuel 8.2	Enable	OFF ON	OFF			
4496	RMI fuel 8.2	Fail class	F1...F8	Warning (F2)			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4500 Wire fail 8							
4501	W. fail 8	Relay output A	Not used Option- dep.	Not used		Designer's Reference Handbook	The wire break fault detection is activated.
4502	W. fail 8	Relay output B	Not used Option- dep.	Not used			
4503	W. fail 8	Enable	OFF ON	OFF			
4504	W. fail 8	Fail class	F1...F8	Warning (F2)			

2.5.4 Speed and running feedback setup

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4510 Overspeed 1							
4511	Over-speed 1	Set point	100.0 % 150.0 %	110.0 %		Designer's Reference Handbook	The set point in percentage relates to nominal RPM.
4512	Over-speed 1	Timer	0.0 s 100.0 s	5.0 s			
4513	Over-speed 1	Relay output A	Not used Option-dep.	Not used			
4514	Over-speed 1	Relay output B	Not used Option-dep.	Not used			
4515	Over-speed 1	Enable	OFF ON	OFF			
4516	Over-speed 1	Fail class	F1...F8	Warn- ing (F2)			
4520 Overspeed 2							
4521	Over-speed 2	Set point	100.0 % 150.0 %	120.0 %		Designer's Reference Handbook	The set point in percentage relates to nominal RPM.
4522	Over-speed 2	Timer	0.0 s 100.0 s	1.0 s			
4523	Over-speed 2	Relay output A	Not used Option-dep.	Not used			
4524	Over-speed 2	Relay output B	Not used Option-dep.	Not used			
4525	Over-speed 2	Enable	OFF ON	OFF			
4526	Over-speed 2	Fail class	F1...F8	Shut- down (F5)			
4530 Crank failure							
4531	Crank failure	Set point	1 RPM 400 RPM	50 RPM		Designer's Reference Handbook	If MPU is chosen as the primary running feedback, this alarm will be raised if the specified RPM is not reached before the delay has expired.
4532	Crank failure	Timer	0.0 s 20.0 s	2.0 s			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4533	Crank failure	Relay output A	Not used Option-dep.	Not used			
4534	Crank failure	Relay output B	Not used Option-dep.	Not used			
4535	Crank failure	Enable	OFF ON	OFF			
4536	Crank failure	Fail class	F1...F8	Warn- ing (F2)			
4540 Running feedback failure							
4541	Run feedb. fail	Timer	0.0 s 20.0 s	2.0 s		Designer's Reference Handbook	If running is detected on the frequency (secondary), but the primary running feedback, e.g. digital input, has not detected running, this alarm will be raised after the adjusted delay time.
4542	Run feedb. fail	Relay output A	Not used Option-dep.	Not used			
4543	Run feedb. fail	Relay output B	Not used Option-dep.	Not used			
4544	Run feedb. fail	Enable	OFF ON	ON			
4545	Run feedb. fail	Fail class	F1...F8	Warn- ing (F2)			
4560 Hz/voltage failure							
4561	Hz/V fail- ure	Timer	1.0 s 99.0 s	30.0 s		Designer's Reference Handbook	If the frequency and voltage are not within the limits after the running feedback is received, this alarm will be raised when the delay time has expired. Limits are placed in menu 2110 (Sync. black-out).
4562	Hz/V fail- ure	Relay output A	Not used Option-dep.	Not used			
4563	Hz/V fail- ure	Relay output B	Not used Option-dep.	Not used			
4564	Hz/V fail- ure	Enable	OFF ON	ON			
4565	Hz/V fail- ure	Fail class	F1...F8	Shut- down (F5)			
4570 Start failure							

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4571	Start failure	Relay output A	Not used Option-dep.	Not used		Designer's Reference Handbook	The start failure alarm occurs if the genset has not started after the number of start attempts.
4572	Start failure	Relay output B	Not used Option-dep.	Not used			
4573	Start failure	Fail class	F1...F8	Block (F1)			
4580 Stop failure							
4581	Stop failure	Timer	10.0 s 120.0 s	30.0 s		Designer's Reference Handbook	A stop failure alarm will appear if the primary running feedback or the generator voltage and frequency are still present after the delay time has expired.
4582	Stop failure	Relay output A	Not used Option-dep.	Not used			
4583	Stop failure	Relay output B	Not used Option-dep.	Not used			
4584	Stop failure	Enable	OFF ON	ON			
4585	Stop failure	Fail class	F1...F8	Shut-down (F5)			
4590 Underspeed 1							
4591	Underspeed	Set point	50.0 % 100.0 %	90.0 %		Designer's Reference Handbook	The set point in percentage relates to nominal RPM.
4592	Underspeed	Timer	0.0 s 100.0 s	5.0 s			
4593	Underspeed	Relay output A	Not used Option-dep.	Not used			
4594	Underspeed	Relay output B	Not used Option-dep.	Not used			
4595	Underspeed	Enable	OFF ON	OFF			
4596	Underspeed	Fail class	F1...F8	Warning (F2)			

2.5.5 Differential measurement

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4600 Delta ana 1/2/3 Inp							
4601	Delta ana1 InpA	Set point	Multi-input 6 EIC	Multi-in- put 6		Designer's Ref- erence Hand- book	Delta analogue Inp 1/2/3 setting. Choose between multi-inputs, external analogue inputs and EIC values
4602	Delta ana1 InpB	Set point	Multi-input 6 EIC	Multi-in- put 6			
4603	Delta ana2 InpA	Set point	Multi-input 6 EIC	Multi-in- put 6			
4604	Delta ana2 InpB	Set point	Multi-input 6 EIC	Multi-in- put 6			
4605	Delta ana3 InpA	Set point	Multi-input 6 EIC	Multi-in- put 6			
4606	Delta ana3 InpB	Set point	Multi-input 6 EIC	Multi-in- put 6			
4610 Delta ana1 1							
4611	Delta ana1 1	Set point	-9999 9999	10		Designer's Ref- erence Hand- book	Delta analogue alarm setting 1.1
4612	Delta ana1 1	Timer	0.0 s 999.0 s	5.0 s			
4613	Delta ana1 1	Relay output A	Not used Option-dep.	Not used			
4614	Delta ana1 1	Relay output B	Not used Option-dep.	Not used			
4615	Delta ana1 1	Enable	OFF ON	OFF			
4616	Delta ana1 1	Fail class	F1...F8	Warning (F2)			
4620 Delta ana1 2							
4621	Delta ana1 2	Set point	-9999 9999	10		Designer's Ref- erence Hand- book	Delta analogue alarm setting 1.2
4622	Delta ana1 2	Timer	0.0 s 999.0 s	5.0 s			
4623	Delta ana1 2	Relay output A	Not used Option-dep.	Not used			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4624	Delta ana1 2	Relay output B	Not used Option-dep.	Not used			
4625	Delta ana1 2	Enable	OFF ON	OFF			
4626	Delta ana1 2	Fail class	F1...F8	Warning (F2)			
4630 Delta ana2 1							
4631	Delta ana2 1	Set point	-9999 9999	10		Designer's Ref- erence Hand- book	Delta analogue alarm setting 2.1
4632	Delta ana2 1	Timer	0.0 s 999.0 s	5.0 s			
4633	Delta ana2 1	Relay output A	Not used Option-dep.	Not used			
4634	Delta ana2 1	Relay output B	Not used Option-dep.	Not used			
4635	Delta ana2 1	Enable	OFF ON	OFF			
4636	Delta ana2 1	Fail class	F1...F8	Warning (F2)			
4640 Delta ana2 2							
4641	Delta ana2 2	Set point	-9999 999	10		Designer's Ref- erence Hand- book	Delta analogue alarm setting 2.2
4642	Delta ana2 2	Timer	0.0 s 999.0 s	5.0 s			
4643	Delta ana2 2	Relay output A	Not used Option-dep.	Not used			
4644	Delta ana2 2	Relay output B	Not used Option-dep.	Not used			
4645	Delta ana2 2	Enable	OFF ON	OFF			
4646	Delta ana2 2	Fail class	F1...F8	Warning (F2)			
4650 Delta ana3 1							
4651	Delta ana3 1	Set point	-9999 9999	10		Designer's Ref- erence Hand- book	Delta analogue alarm setting 3.1
4652	Delta ana3 1	Timer	0.0 s 999.0 s	5.0 s			
4653	Delta ana3 1	Relay output A	Not used Option-dep.	Not used			
4654	Delta ana3 1	Relay output B	Not used Option-dep.	Not used			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4655	Delta ana3 1	Enable	OFF ON	OFF			
4656	Delta ana3 1	Fail class	F1...F8	Warning (F2)			
4660 Delta ana3 2							
4661	Delta ana3 2	Set point	-9999 9999	10		Designer's Ref- erence Hand- book	Delta analogue alarm setting 3.2
4662	Delta ana3 2	Timer	0.0 s 999.0 s	5.0 s			
4663	Delta ana3 2	Relay output A	Not used Option-dep.	Not used			
4664	Delta ana3 2	Relay output B	Not used Option-dep.	Not used			
4665	Delta ana3 2	Enable	OFF ON	OFF			
4666	Delta ana3 2	Fail class	F1...F8	Warning (F2)			

2.5.6 Aux. supply setup

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4960 U< auxiliary power supply terminal 1							
4961	U< aux. term. 1	Set point	8.0 V _{dc} 32.0 V _{dc}	18.0 V _{dc}		Designer's Reference Handbook	The power supply on terminal 1 and 2 has been continu- ously below the adjusted set point during the programmed delay.
4962	U< aux. term. 1	Timer	10.0 s 999.0 s	10.0 s			
4963	U< aux. term. 1	Relay output A	Not used Option- dep.	Not used			
4964	U< aux. term. 1	Relay output B	Not used Option- dep.	Not used			
4965	U< aux. term. 1	Enable	OFF ON	ON			
4966	U< aux. term. 1	Fail class	F1...F8	Warning (F2)			
4970 U> auxiliary power supply terminal 1							
4971	U> aux. term. 1	Set point	12.0 V _{dc} 36.0 V _{dc}	30.0 V _{dc}		Designer's Reference Handbook	The power supply on terminal 1 and 2 has been continu- ously above the adjusted set point during the programmed delay.
4972	U> aux. term. 1	Timer	10.0 s 999.0 s	10.0 s			
4973	U> aux. term. 1	Relay output A	Not used Option- dep.	Not used			
4974	U> aux. term. 1	Relay output B	Not used Option- dep.	Not used			
4975	U> aux. term. 1	Enable	OFF ON	ON			
4976	U> aux. term. 1	Fail class	F1...F8	Warning (F2)			

2.5.7 Multi-input no. 58



The available menus for multi-input no. 58 depend on the input type configured in the PC utility software (menu 11300).

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4740 Digital input 58							
4741	Dig. in- put 58	Enable	OFF ON	OFF		Designer's Reference Handbook	The input is configurable and can have different functions in different units. The multi-input 58 has been configured as 'Binary'.
4742	Dig. in- put 58	Timer	0.0 s 999.0 s	10.0 s			
4743	Dig. in- put 58	Relay output A	Not used Option- dep.	Not used			
4744	Dig. in- put 58	Relay output B	Not used Option- dep.	Not used			
4745	Dig. in- put 58	Enable	OFF ON	OFF			
4746	Dig. in- put 58	Fail class	F1...F8	Warning (F2)			
4740 4-20 mA 58.1							
4741	4-20 mA 58.1	Set point	4 mA 20 mA	10 mA		Designer's Reference Handbook	The multi-input 58 has been configured as '4-20 mA'.
4742	4-20 mA 58.1	Timer	0.0 s 999.0 s	120.0 s			
4743	4-20 mA 58.1	Relay output A	Not used Option- dep.	Not used			
4744	4-20 mA 58.1	Relay output B	Not used Option- dep.	Not used			
4745	4-20 mA 58.1	Enable	OFF ON	OFF			
4746	4-20 mA 58.1	Fail class	F1...F8	Warning (F2)			
4750 4-20 mA 58.2							

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4751	4-20 mA 58.2	Set point	4 mA 20 mA	10 mA		Designer's Reference Handbook	The multi-input 58 has been configured as '4-20 mA'.
4752	4-20 mA 58.2	Timer	0.0 s 999.0 s	120.0 s			
4753	4-20 mA 58.2	Relay output A	Not used Option- dep.	Not used			
4754	4-20 mA 58.2	Relay output B	Not used Option- dep.	Not used			
4755	4-20 mA 58.2	Enable	OFF ON	OFF			
4756	4-20 mA 58.2	Fail class	F1...F8	Warning (F2)			
4740 Pt100/Pt1000 58.1							
4741	PT 58.1	Set point	-49 482	80		Designer's Reference Handbook	The multi-input 58 has been configured as 'Pt100' or 'Pt1000'. Pt100/Pt1000 set point can be in deg. C or F, dependent on the unit selection (menu 10970).
4742	PT 58.1	Timer	0.0 s 999.0 s	5.0 s			
4743	PT 58.1	Relay output A	Not used Option- dep.	Not used			
4744	PT 58.1	Relay output B	Not used Option- dep.	Not used			
4745	PT 58.1	Enable	OFF ON	OFF			
4746	PT 58.1	Fail class	F1...F8	Warning (F2)			
4750 Pt100/Pt1000 58.2							
4751	PT 58.2	Set point	-49 482	80		Designer's Reference Handbook	The multi-input 58 has been configured as 'Pt100' or 'Pt1000'. Pt100/Pt1000 set point can be in deg. C or F, dependent on the unit selection (menu 10970).
4752	PT 58.2	Timer	0.0 s 999.0 s	10.0 s			
4753	PT 58.2	Relay output A	Not used Option- dep.	Not used			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4754	PT 58.2	Relay output B	Not used Option- dep.	Not used			
4755	PT 58.2	Enable	OFF ON	OFF			
4756	PT 58.2	Fail class	F1...F8	Warning (F2)			
4740 Resistance measurement input, oil pressure 58.1							
4741	RMI oil 58.1	Set point	0.0 145.0	2.0		Designer's Reference Handbook	The multi-input 58 has been configured as 'RMI oil pres- sure'. Oil pressure set point can be in Bar or PSI, dependent on the unit selection (menu 10970).
4742	RMI oil 58.1	Timer	0.0 s 999.0 s	5.0 s			
4743	RMI oil 58.1	Relay output A	Not used Option- dep.	Not used			
4744	RMI oil 58.1	Relay output B	Not used Option- dep.	Not used			
4745	RMI oil 58.1	Enable	OFF ON	OFF			
4746	RMI oil 58.1	Fail class	F1...F8	Warning (F2)			
4750 Resistance measurement input, oil pressure 58.2							
4751	RMI oil 58.2	Set point	0.0 145.0	1.0		Designer's Reference Handbook	The multi-input 58 has been configured as 'RMI oil pres- sure'. Oil pressure set point can be in Bar or PSI, dependent on the unit selection (menu 10970).
4752	RMI oil 58.2	Timer	0.0 s 999.0 s	5.0 s			
4753	RMI oil 58.2	Relay output A	Not used Option- dep.	Not used			
4754	RMI oil 58.2	Relay output B	Not used Option- dep.	Not used			
4755	RMI oil 58.2	Enable	OFF ON	OFF			
4756	RMI oil 58.2	Fail class	F1...F8	Shut- down (F5)			
4740 Resistance measurement input, water temperature 58.1							
4741	RMI water 58.1	Set point	-49 482	100		Designer's Reference Handbook	The multi-input 58 has been configured as 'RMI water tem- perature'.

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4742	RMI water 58.1	Timer	0.0 s 999.0 s	5.0 s			Water temperature set point can be in deg. C or F, depend- ent on the unit selection (menu 10970).
4743	RMI water 58.1	Relay output A	Not used Option- dep.	Not used			
4744	RMI water 58.1	Relay output B	Not used Option- dep.	Not used			
4745	RMI water 58.1	Enable	OFF ON	OFF			
4746	RMI water 58.1	Fail class	F1...F8	Warning (F2)			
4750 Resistance measurement input, water temperature 58.2							
4751	RMI water 58.2	Set point	-49 482	110		Designer's Reference Handbook	The multi-input 58 has been configured as 'RMI water tem- perature'. Water temperature set point can be in deg. C or F, depend- ent on the unit selection (menu 10970).
4752	RMI water 58.2	Timer	0.0 s 999.0 s	5.0 s			
4753	RMI water 58.2	Relay output A	Not used Option- dep.	Not used			
4754	RMI water 58.2	Relay output B	Not used Option- dep.	Not used			
4755	RMI water 58.2	Enable	OFF ON	OFF			
4756	RMI water 58.2	Fail class	F1...F8	Trip + Stop (F4)			
4740 Resistance measurement input, fuel level 58.1							
4741	RMI fuel 58.1	Set point	0 % 100 %	10 %		Designer's Reference Handbook	The multi-input 58 has been configured as 'RMI fuel level'.
4742	RMI fuel 58.1	Timer	0.0 s 999.0 s	10.0 s			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4743	RMI fuel 58.1	Relay output A	Not used Option- dep.	Not used			
4744	RMI fuel 58.1	Relay output B	Not used Option- dep.	Not used			
4745	RMI fuel 58.1	Enable	OFF ON	OFF			
4746	RMI fuel 58.1	Fail class	F1...F8	Warning (F2)			
4750 Resistance measurement input, fuel level 58.2							
4751	RMI fuel 58.2	Set point	0 % 100 %	5 %		Designer's Reference Handbook	The multi-input 58 has been configured as 'RMI fuel level'.
4752	RMI fuel 58.2	Timer	0.0 s 999.0 s	10.0 s			
4753	RMI fuel 58.2	Relay output A	Not used Option- dep.	Not used			
4754	RMI fuel 58.2	Relay output B	Not used Option- dep.	Not used			
4755	RMI fuel 58.2	Enable	OFF ON	OFF			
4756	RMI fuel 58.2	Fail class	F1...F8	Warning (F2)			
4760 Wire fail 58							
4761	W. fail 58	Relay output A	Not used Option- dep.	Not used		Designer's Reference Handbook	The wire break fault detection is activated.
4762	W. fail 58	Relay output B	Not used Option- dep.	Not used			
4763	W. fail 58	Enable	OFF ON	OFF			
4764	W. fail 58	Fail class	F1...F8	Warning (F2)			

2.5.8 Multi-input no. 59



The available menus for multi-input no. 59 depend on the input type configured in the PC utility software (menu 11310).

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4770 Digital input 59							
4771	Dig. in- put 59	Enable	OFF ON	OFF		Designer's Reference Handbook	The input is configurable and can have different functions in different units. The multi-input 59 has been configured as 'Binary'.
4772	Dig. in- put 59	Timer	0.0 s 999.0 s	10.0 s			
4773	Dig. in- put 59	Relay output A	Not used Option- dep.	Not used			
4774	Dig. in- put 59	Relay output B	Not used Option- dep.	Not used			
4775	Dig. in- put 59	Enable	OFF ON	OFF			
4776	Dig. in- put 59	Fail class	F1...F8	Warning (F2)			
4770 4-20 mA 59.1							
4771	4-20 mA 59.1	Set point	4 mA 20 mA	10 mA		Designer's Reference Handbook	The multi-input 59 has been configured as '4-20 mA'.
4772	4-20 mA 59.1	Timer	0.0 s 999.0 s	120.0 s			
4773	4-20 mA 59.1	Relay output A	Not used Option- dep.	Not used			
4774	4-20 mA 59.1	Relay output B	Not used Option- dep.	Not used			
4775	4-20 mA 59.1	Enable	OFF ON	OFF			
4776	4-20 mA 59.1	Fail class	F1...F8	Warning (F2)			
4780 4-20 mA 59.2							

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4781	4-20 mA 59.2	Set point	4 mA 20 mA	10 mA		Designer's Reference Handbook	The multi-input 59 has been configured as '4-20 mA'.
4782	4-20 mA 59.2	Timer	0.0 s 999.0 s	120.0 s			
4783	4-20 mA 59.2	Relay output A	Not used Option- dep.	Not used			
4784	4-20 mA 59.2	Relay output B	Not used Option- dep.	Not used			
4785	4-20 mA 59.2	Enable	OFF ON	OFF			
4786	4-20 mA 59.2	Fail class	F1...F8	Warning (F2)			
4770 Pt100/Pt1000 59.1							
4771	PT 59.1	Set point	-49 482	80		Designer's Reference Handbook	The multi-input 59 has been configured as 'Pt100' or 'Pt1000'. Pt100/Pt1000 set point can be in deg. C or F, dependent on the unit selection (menu 10970).
4772	PT 59.1	Timer	0.0 s 999.0 s	5.0 s			
4773	PT 59.1	Relay output A	Not used Option- dep.	Not used			
4774	PT 59.1	Relay output B	Not used Option- dep.	Not used			
4775	PT 59.1	Enable	OFF ON	OFF			
4776	PT 59.1	Fail class	F1...F8	Warning (F2)			
4780 Pt100/Pt1000 59.2							
4781	PT 59.2	Set point	-49 482	80		Designer's Reference Handbook	The multi-input 59 has been configured as 'Pt100' or 'Pt1000'. Pt100/Pt1000 set point can be in deg. C or F, dependent on the unit selection (menu 10970).
4782	PT 59.2	Timer	0.0 s 999.0 s	10.0 s			
4783	PT 59.2	Relay output A	Not used Option- dep.	Not used			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4784	PT 59.2	Relay output B	Not used Option- dep.	Not used			
4785	PT 59.2	Enable	OFF ON	OFF			
4786	PT 59.2	Fail class	F1...F8	Warning (F2)			
4770 Resistance measurement input, oil pressure 59.1							
4771	RMI oil 59.1	Set point	0.0 145.0	2.0		Designer's Reference Handbook	The multi-input 59 has been configured as 'RMI oil pres- sure'. Oil pressure set point can be in Bar or PSI, dependent on the unit selection (menu 10970).
4772	RMI oil 59.1	Timer	0.0 s 999.0 s	5.0 s			
4773	RMI oil 59.1	Relay output A	Not used Option- dep.	Not used			
4774	RMI oil 59.1	Relay output B	Not used Option- dep.	Not used			
4775	RMI oil 59.1	Enable	OFF ON	OFF			
4776	RMI oil 59.1	Fail class	F1...F8	Warning (F2)			
4780 Resistance measurement input, oil pressure 59.2							
4781	RMI oil 59.2	Set point	0.0 145.0	1.0		Designer's Reference Handbook	The multi-input 59 has been configured as 'RMI oil pres- sure'. Oil pressure set point can be in Bar or PSI, dependent on the unit selection (menu 10970).
4782	RMI oil 59.2	Timer	0.0 s 999.0 s	5.0 s			
4783	RMI oil 59.2	Relay output A	Not used Option- dep.	Not used			
4784	RMI oil 59.2	Relay output B	Not used Option- dep.	Not used			
4785	RMI oil 59.2	Enable	OFF ON	OFF			
4786	RMI oil 59.2	Fail class	F1...F8	Shut- down (F5)			
4770 Resistance measurement input, water temperature 59.1							
4771	RMI water 59.1	Set point	-49 482	100		Designer's Reference Handbook	The multi-input 59 has been configured as 'RMI water tem- perature'.

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4772	RMI water 59.1	Timer	0.0 s 999.0 s	5.0 s			Water temperature set point can be in deg. C or F, depend- ent on the unit selection (menu 10970).
4773	RMI water 59.1	Relay output A	Not used Option- dep.	Not used			
4774	RMI water 59.1	Relay output B	Not used Option- dep.	Not used			
4775	RMI water 59.1	Enable	OFF ON	OFF			
4776	RMI water 59.1	Fail class	F1...F8	Warning (F2)			
4780 Resistance measurement input, water temperature 59.2							
4781	RMI water 59.2	Set point	-49 482	110		Designer's Reference Handbook	The multi-input 59 has been configured as 'RMI water tem- perature'. Water temperature set point can be in deg. C or F, depend- ent on the unit selection (menu 10970).
4782	RMI water 59.2	Timer	0.0 s 999.0 s	5.0 s			
4783	RMI water 59.2	Relay output A	Not used Option- dep.	Not used			
4784	RMI water 59.2	Relay output B	Not used Option- dep.	Not used			
4785	RMI water 59.2	Enable	OFF ON	OFF			
4786	RMI water 59.2	Fail class	F1...F8	Trip + Stop (F4)			
4770 Resistance measurement input, fuel level 59.1							
4771	RMI fuel 59.1	Set point	0 % 100 %	10 %		Designer's Reference Handbook	The multi-input 59 has been configured as 'RMI fuel level'.
4772	RMI fuel 59.1	Timer	0.0 s 999.0 s	10.0 s			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4773	RMI fuel 59.1	Relay output A	Not used Option- dep.	Not used			
4774	RMI fuel 59.1	Relay output B	Not used Option- dep.	Not used			
4775	RMI fuel 59.1	Enable	OFF ON	OFF			
4776	RMI fuel 59.1	Fail class	F1...F8	Warning (F2)			
4780 Resistance measurement input, fuel level 59.2							
4781	RMI fuel 59.2	Set point	0 % 100 %	5 %		Designer's Reference Handbook	The multi-input 59 has been configured as 'RMI fuel level'.
4782	RMI fuel 59.2	Timer	0.0 s 999.0 s	10.0 s			
4783	RMI fuel 59.2	Relay output A	Not used Option- dep.	Not used			
4784	RMI fuel 59.2	Relay output B	Not used Option- dep.	Not used			
4785	RMI fuel 59.2	Enable	OFF ON	OFF			
4786	RMI fuel 59.2	Fail class	F1...F8	Warning (F2)			
4790 Wire fail 59							
4791	W. fail 59	Relay output A	Not used Option- dep.	Not used		Designer's Reference Handbook	The wire break fault detection is activated.
4792	W. fail 59	Relay output B	Not used Option- dep.	Not used			
4793	W. fail 59	Enable	OFF ON	OFF			
4794	W. fail 59	Fail class	F1...F8	Warning (F2)			

2.6 System parameters, general setup

2.6.1 Engine heater failure

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6330 Engine heater 1							
6331	Engine heater 1	Set point	10 deg 250 deg	30 deg		Designer's Reference Handbook	
6332	Engine heater 1	Timer	1.0 s 300.0 s	10.0 s			
6333	Engine heater 1	Relay out- put A	Not used Option-dep.	Not used			
6334	Engine heater 1	Relay out- put B	Not used Option-dep.	Not used			
6335	Engine heater 1	Enable	OFF ON	OFF			
6336	Engine heater 1	Fail class	F1...F8	Warning (F2)			

2.6.2 Max. ventilation

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6470 Max vent 1							
6471	Max vent 1	Set point	20 deg 250 deg	95 deg		Designer's Reference Handbook	If the cooling fans fail to operate and the coolant temperature exceeds the setting, the alarm will activate.
6472	Max vent 1	Timer	0.0 s 60.0 s	1.0 s			
6473	Max vent 1	Relay output A	Not used Option- dep.	Not used			
6474	Max vent 1	Relay output B	Not used Option- dep.	Not used			
6475	Max vent 1	Enable	OFF ON	OFF			
6476	Max vent 1	Fail class	F1...F8	Warning (F2)			
6480 Max vent 2							
6481	Max vent 2	Set point	20 deg 250 deg	98 deg		Designer's Reference Handbook	If the cooling fans fail to operate and the coolant temperature exceeds the setting, the alarm will activate.
6482	Max vent 2	Timer	0.0 s 60.0 s	1.0 s			
6483	Max vent 2	Relay output A	Not used Option- dep.	Not used			
6484	Max vent 2	Relay output B	Not used Option- dep.	Not used			
6485	Max vent 2	Enable	OFF ON	OFF			
6486	Max vent 2	Fail class	F1...F8	Shut- down (F5)			

2.6.3 Switchboard error - Block and Stop

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6500 Block switchboard error							
6501	Blk. swbd er- ror	Timer	0.0 s 999.0 s	10.0 s		Designer's Reference Handbook	If the binary input “switchboard error” activates, a stopped gen- erator will be blocked for start. Parameter 6502: OFF: Only AMF start is affec- ted. ON: All starts are affected.
6502	Blk. swbd er- ror	Parallel	ON OFF	OFF			
6503	Blk. swbd er- ror	Relay output A	Not used Option- dep.	Not used			
6504	Blk. swbd er- ror	Relay output B	Not used Option- dep.	Not used			
6505	Blk. swbd er- ror	Enable	OFF ON	OFF			
6506	Blk. swbd er- ror	Fail class	F1...F8	Warning (F2)			
6510 Stop switchboard error							
6511	Stp. swbd er- ror	Timer	0.0 s 999.0 s	1.0 s		Designer's Reference Handbook	If the binary input “switchboard error” activates, the generator will be stopped.
6512	Stp. swbd er- ror	Relay output A	Not used Option- dep.	Not used			
6513	Stp. swbd er- ror	Relay output B	Not used Option- dep.	Not used			
6514	Stp. swbd er- ror	Enable	OFF ON	OFF			
6515	Stp. swbd er- ror	Fail class	F1...F8	Shut- down (F5)			

2.6.4 Switchboard error - Not in auto

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6540 Not in auto							
6541	Not in auto	Timer	10.0 s 900.0 s	300.0 s		Designer's Reference Handbook	
6542	Not in auto	Relay output A	Not used Option-dep.	Not used			
6543	Not in auto	Relay output B	Not used Option-dep.	Not used			
6544	Not in auto	Enable	OFF ON	OFF			
6545	Not in auto	Fail class	F1...F8	Warning (F2)			

2.6.5 Avg U BB

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
7480 Avg U BB> 1							
7481	Avg U BB> 1	Set point	100.0 % 120.0 %	110.0 %			
7482	Avg U BB> 1	Timer	0.1 s 3200.0 s	10.0 s			
7483	Avg U BB> 1	Relay output A	Not used Option-dep.	Not used			
7484	Avg U BB> 1	Enable	OFF ON	OFF			
7485	Avg U BB> 1	Fail class	F1...F8	Warning (F2)			
7486	Avg U BB> 1	AVG timer	30.0 s 900.0 s	600.0 s			
7490 Avg U BB> 2							
7491	Avg U BB> 2	Set point	100.0 % 120.0 %	110.0 %			
7492	Avg U BB> 2	Timer	0.1 s 3200.0 s	10.0 s			
7493	Avg U BB> 2	Relay output A	Not used Option-dep.	Not used			
7494	Avg U BB> 2	Enable	OFF ON	OFF			
7495	Avg U BB> 2	Fail class	F1...F8	Warning (F2)			
7496	Avg U BB> 2	AVG timer	30.0 s 900.0 s	600.0 s			

2.7 System parameters, communication

2.7.1 External communication error

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
7520 External communication error							
7521	Ext. comm. er- ror	Delay	1.0 s 100.0 s	10.0 s		Option: Modbus (H2)	Supervision of the external communication line. The alarm will occur when there has not been any com- munication during the time de- lay.
7522	Ext. comm. er- ror	Relay output A	Not used Option- dep.	Not used			
7523	Ext. comm. er- ror	Relay output B	Not used Option- dep.	Not used			
7524	Ext. comm. er- ror	Enable	OFF ON	OFF			
7525	Ext. comm. er- ror	Fail class	F1...F8	Warning (F2)			

2.7.2 Engine interface communication alarms

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
7570 EI comm. error							
7571	EI comm. error	Timer	0.0 s 100.0 s	0.0 s		Option: H5	Supervision of the EIC communication line. The alarm will occur when there has not been any communication during the time delay.
7572	EI comm. error	Relay output A	Not used Option-dep.	Not used			
7573	EI comm. error	Relay output B	Not used Option-dep.	Not used			
7574	EI comm. error	Enable	OFF ON	OFF			
7575	EI comm. error	Fail class	F1...F8	Warning (F2)			
7580 EIC warning							
7581	EIC warning	Timer	0.0 s 100.0 s	0.0 s		Option: H5	
7582	EIC warning	Relay output A	Not used Option-dep.	Not used			
7583	EIC warning	Relay output B	Not used Option-dep.	Not used			
7584	EIC warning	Enable	OFF ON	OFF			
7585	EIC warning	Fail class	F1...F8	Warning (F2)			
7590 EIC shutdown							
7591	EIC shutdown	Timer	0.0 s 100.0 s	0.0 s		Option: H5	
7592	EIC shutdown	Relay output A	Not used Option-dep.	Not used			
7593	EIC shutdown	Relay output B	Not used Option-dep.	Not used			
7594	EIC shutdown	Enable	OFF ON	OFF			
7595	EIC shutdown	Fail class	F1...F8	Shutdown (F5)			
7600 EIC overspeed							
7601	EIC overspeed	Set point	100.0 % 150.0 %	110.0 %		Option: H5	
7602	EIC overspeed	Timer	0.0 s 100.0 s	5.0 s			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
7603	EIC overspeed	Relay output A	Not used Option-dep.	Not used			
7604	EIC overspeed	Relay output B	Not used Option-dep.	Not used			
7605	EIC overspeed	Enable	OFF ON	OFF			
7606	EIC overspeed	Fail class	F1...F8	Warning (F2)			
7610 EIC Coolant temp. 1							
7611	EIC coolant t. 1	Set point	-40 deg 410 deg	100 deg		Option: H5	
7612	EIC coolant t. 1	Timer	0.0 s 100.0 s	5.0 s			
7613	EIC coolant t. 1	Relay output A	Not used Option-dep.	Not used			
7614	EIC coolant t. 1	Relay output B	Not used Option-dep.	Not used			
7615	EIC coolant t. 1	Enable	OFF ON	OFF			
7616	EIC coolant t. 1	Fail class	F1...F8	Warning (F2)			
7620 EIC Coolant temp. 2							
7621	EIC coolant t. 2	Set point	-40 deg 410 deg	110 deg		Option: H5	
7622	EIC coolant t. 2	Timer	0.0 s 100.0 s	5.0 s			
7623	EIC coolant t. 2	Relay output A	Not used Option-dep.	Not used			
7624	EIC coolant t. 2	Relay output B	Not used Option-dep.	Not used			
7625	EIC coolant t. 2	Enable	OFF ON	OFF			
7626	EIC coolant t. 2	Fail class	F1...F8	Warning (F2)			
7630 EIC Oil pressure 1							
7631	EIC oil press. 1	Set point	0.0 bar 145.0 bar	2.0 bar		Option: H5	
7632	EIC oil press. 1	Timer	0.0 s 100.0 s	5.0 s			
7633	EIC oil press. 1	Relay output A	Not used Option-dep.	Not used			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
7634	EIC oil press. 1	Relay output B	Not used Option-dep.	Not used			
7635	EIC oil press. 1	Enable	OFF ON	OFF			
7636	EIC oil press. 1	Fail class	F1...F8	Warning (F2)			
7640 EIC Oil pressure 2							
7641	EIC oil press. 2	Set point	0.0 bar 145.0 bar	1.0 bar		Option: H5	
7642	EIC oil press. 2	Timer	0.0 s 100.0 s	5.0 s			
7643	EIC oil press. 2	Relay output A	Not used Option-dep.	Not used			
7644	EIC oil press. 2	Relay output B	Not used Option-dep.	Not used			
7645	EIC oil press. 2	Enable	OFF ON	OFF			
7646	EIC oil press. 2	Fail class	F1...F8	Shutdown (F5)			
7650 EIC Oil temp 1							
7651	EIC oil temp. 1	Set point	0 deg 410 deg	40 deg		Option: H5	
7652	EIC oil temp. 1	Timer	0.0 s 100.0 s	5.0 s			
7653	EIC oil temp. 1	Relay output A	Not used Option-dep.	Not used			
7654	EIC oil temp. 1	Relay output B	Not used Option-dep.	Not used			
7655	EIC oil temp. 1	Enable	OFF ON	OFF			
7656	EIC oil temp. 1	Fail class	F1...F8	Warning (F2)			
7660 EIC Oil temp 2							
7661	EIC oil temp. 2	Set point	0 deg 410 deg	50 deg		Option: H5	
7662	EIC oil temp. 2	Timer	0.0 s 100.0 s	5.0 s			
7663	EIC oil temp. 2	Relay output A	Not used Option-dep.	Not used			
7664	EIC oil temp. 2	Relay output B	Not used Option-dep.	Not used			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
7665	EIC oil temp. 2	Enable	OFF ON	OFF			
7666	EIC oil temp. 2	Fail class	F1...F8	Shutdown (F5)			
7670 EIC Coolant level 1							
7671	EIC coolant level 1	Set point	0 % 100 %	20 %		Option: H5	
7672	EIC coolant level 1	Timer	0.0 s 100.0 s	5.0 s			
7673	EIC coolant level 1	Relay output A	Not used Option-dep.	Not used			
7674	EIC coolant level 1	Relay output B	Not used Option-dep.	Not used			
7675	EIC coolant level 1	Enable	OFF ON	OFF			
7676	EIC coolant level 1	Fail class	F1...F8	Warning (F2)			
7680 EIC Coolant level 2							
7681	EIC coolant level 2	Set point	0 % 100 %	10 %		Option: H5	
7682	EIC coolant level 2	Timer	0.0 s 100.0 s	5.0 s			
7683	EIC coolant level 2	Relay output A	Not used Option-dep.	Not used			
7684	EIC coolant level 2	Relay output B	Not used Option-dep.	Not used			
7685	EIC coolant level 2	Enable	OFF ON	OFF			
7686	EIC coolant level 2	Fail class	F1...F8	Shutdown (F5)			

3. Parameter list

3.1 General information about the parameter list

3.1.1 Parameter list settings

The parameter list contains settings for regulators and other non-alarm-related settings.

3.2 Control parameter, regulation

3.2.1 Regulation

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
2770 EIC speed control							
2771	Scania control	Droop	0.0 % 25.0 %	0.0 %	Only applica- ble if "Scania" is selected in menu 7561.	Option H5	Setting of speed control via engine communication in- terface.
2772	Scania control	RPM	User 1500 RPM 1800 RPM Low idle	User			
2773	Cummins Gain	Kp	0.00 10.00	5.00	Only applica- ble when "Cummins" is selected in menu 7561.		
2790 EIC speed demand switch							
2791	EIC speed dem. sw.	Local norm sw.	Ana. CAN Up/Down ECU Up/Down CAN Ana. ECU Ana. ECU rel. Frequency	Ana. CAN		Option H5	See description in option H5 manual.
2792	EIC speed dem. sw.	Local Emerg sw.	Ana. CAN Up/Down ECU Up/Down CAN Ana. ECU Ana. ECU rel. Frequency	Ana. CAN			
2793	EIC speed dem. sw.	Remote norm sw.	Ana. CAN Up/Down ECU Up/Down CAN Ana. ECU Ana. ECU rel. Frequency	Ana. CAN			
2794	EIC speed dem. sw.	Remote Emerg sw.	Ana. CAN Up/Down ECU Up/Down CAN Ana. ECU Ana. ECU rel. Frequency	Ana. CAN			

3.3 Control parameters, output setup

3.3.1 Digital output setup

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
5000 Relay 03							
5001	Relay 03	Function	Alarm relay ND Alarm relay NE	Horn relay		Designer's Ref- erence Hand- book	Function selections: - Alarm relay ND - Limit relay - Horn relay - Alarm relay NE
5002	Relay 03	OFF de- lay	0.0 s 999.9 s	5.0 s			
5010 Relay 21							
5011	Relay 21	Function	Alarm relay ND Alarm relay NE	Alarm re- lay ND		Designer's Ref- erence Hand- book	Function selections: - Alarm relay ND - Limit relay - Horn relay - Alarm relay NE
5012	Relay 21	OFF de- lay	0.0 s 999.9 s	5.0 s			
5020 Relay 22							
5021	Relay 22	Function	Alarm relay ND Alarm relay NE	Alarm re- lay ND		Designer's Ref- erence Hand- book	Function selections: - Alarm relay ND - Limit relay - Horn relay - Alarm relay NE
5022	Relay 22	OFF de- lay	0.0 s 999.9 s	5.0 s			
5030 Relay 23							
5031	Relay 23	Function	Alarm relay ND Alarm relay NE	Alarm re- lay ND		Designer's Ref- erence Hand- book	Function selections: - Alarm relay ND - Limit relay - Horn relay - Alarm relay NE
5032	Relay 23	OFF de- lay	0.0 s 999.9 s	5.0 s			
5040 Relay 24							
5041	Relay 24	Function	Alarm relay ND Alarm relay NE	Alarm re- lay ND		Designer's Ref- erence Hand- book	Function selections: - Alarm relay ND - Limit relay - Horn relay - Alarm relay NE
5042	Relay 24	OFF de- lay	0.0 s 999.9 s	5.0 s			
5050 Relay 26							

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
5051	Relay 26	Function	Alarm relay ND Alarm relay NE	Alarm re- lay ND		Designer's Ref- erence Hand- book	Function selections: - Alarm relay ND - Limit relay - Horn relay - Alarm relay NE
5052	Relay 26	OFF de- lay	0.0 s 999.9 s	5.0 s			
5060 Relay 45							
5061	Relay 45	Function	Alarm relay ND Alarm relay NE	Alarm re- lay ND		Designer's Ref- erence Hand- book	Function selections: - Alarm relay ND - Limit relay - Horn relay - Alarm relay NE
5062	Relay 45	OFF de- lay	0.0 s 999.9 s	5.0 s			
5070 Relay 47							
5071	Relay 47	Function	Alarm relay ND Alarm relay NE	Alarm re- lay ND		Designer's Ref- erence Hand- book	Function selections: - Alarm relay ND - Limit relay - Horn relay - Alarm relay NE
5072	Relay 47	OFF de- lay	0.0 s 999.9 s	5.0 s			

3.4 System parameters



These menus include parameters for the system setup.

3.5 System parameters, general setup

3.5.1 General setup

No.	Setting		Min. Max.	Facto- ry set- ting	Notes	Ref.	Description
6000 Nominal settings 1							
6001	Nom. set- tings 1	Fre- quency	48.0 Hz 62.0 Hz	50.0 Hz		Designer's Reference Handbook	The selection of nominal settings to be used is set in menu 6006. A binary in- put or selection in M-Logic can also be used. Scaling of power and voltage range is dependent on pa- rameter 9030.
6002	Nom. set- tings 1	Power	10 kW 90.00 MW	480 kW			
6003	Nom. set- tings 1	Current	0 A 9000 A	867 A			
6004	Nom. set- tings 1	Voltage	100 V 75 kV	400 V			
6005	Nom. set- tings 1	RPM	100 RPM 4000 RPM	1500 RPM			
6006	Nom. set- tings 1	Setting	1 4	1			
6010 Nominal settings 2							
6011	Nom. set- tings 2	Fre- quency	48.0 Hz 62.0 Hz	50.0 Hz		Designer's Reference Handbook	
6012	Nom. set- tings 2	Power	10 kW 90.00 MW	230 kW			
6013	Nom. set- tings 2	Current	0 A 9000 A	345 A			
6014	Nom. set- tings 2	Voltage	100 V 75 kV	480 V			
6015	Nom. set- tings 2	RPM	100 RPM 4000 RPM	1500 RPM			
6020 Nominal settings 3							
6021	Nom. set- tings 3	Fre- quency	48.0 Hz 62.0 Hz	60.0 Hz		Designer's Reference Handbook	
6022	Nom. set- tings 3	Power	10 kW 90.00 MW	230 kW			
6023	Nom. set- tings 3	Current	0 A 9000 A	345 A			
6024	Nom. set- tings 3	Voltage	100 V 75 kV	480 V			
6025	Nom. set- tings 3	RPM	100 RPM 4000 RPM	1800 RPM			
6030 Nominal settings 4							

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6031	Nom. settings 4	Frequency	48.0 Hz 62.0 Hz	60.0 Hz		Designer's Reference Handbook	
6032	Nom. settings 4	Power	10 kW 90.00 kW	230 kW			
6033	Nom. settings 4	Current	0 A 9000 A	345 A			
6034	Nom. settings 4	Voltage	100 V 75 kV	480 V			
6035	Nom. settings 4	RPM	100 RPM 4000 RPM	1800 RPM			
6040 G transformer							
6041	G transformer	U primary	100 V 75 kV	400 V		Designer's Reference Handbook	If no voltage transformer is present, the primary and secondary side values are set to generator nominal value.
6042	G transformer	U secondary	100 V 480 V	400 V			
6043	G transformer	I primary	5 A 9000 A	1000 A			
6044	G transformer	I secondary	1 A 5 A	1 A			
6050 Busbar settings							
6051	BB transformer	U primary	100 V 75 kV	400 V		Designer's Reference Handbook	If no voltage transformer is present, the primary and secondary side values are set to generator nominal value.
6052	BB transformer	U secondary	100 V 480 V	400 V			
6053	BB transformer	Nominal U 1	100 V 75 kV	400 V			
6054	BB transformer	Bus nom. set	Param set 1 Param set 2	Param set 1			
6060 Busbar settings 2							
6061	BB transformer	U primary	100 V 75 kV	400 V		Designer's Reference Handbook	If no voltage transformer is present, the primary and secondary side values are set to generator nominal value.
6062	BB transformer	U secondary	100 V 480 V	400 V			
6063	BB transformer	Nominal U 2	100 V 75 kV	400 V			
6070 Genset mode							

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6071	Genset mode		Island Load take-over			Designer's Reference Handbook	Selections are: -Island -Auto Mains Failure -Load takeover
6080 Language							
6081	Language		English Language 3	English		Designer's Reference Handbook	The master language is English. Additionally, 11 different languages can be configured with the PC utility software. Only 3 different languages can be written to the controller.

3.5.2 Counters and timers

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6100 Counters							
6101	Counters	Run.H. *1	0 hrs 999 hrs	0 hour		Designer's Reference Handbook	Setting 6105 resets the kWh counter to 0. It auto- matically reverts to OFF after being set ON.
6102	Counters	Run.H. *1000	0 hrs 999 hrs	0 hour			
6103	Counters	GB oper- ations	0 20000	0			
6104	Counters	MB oper- ations	0 20000	0			
6105	Counters	kWh	OFF ON	OFF			
6106	Counters	Start at- tempts	0 20000	0			
6110 Service timer 1							
6111	Service timer 1	Enable	OFF ON	ON		Designer's Reference Handbook	The timer is reset by ena- bling menu 6116. The menu automatically goes OFF.
6112	Service timer 1	Hours timer	0 hrs 9000 hrs	500 hrs			
6113	Service timer 1	Days tim- er	1 days 1000 days	365 days			
6114	Service timer 1	Fail class	F1...F8	F2 (Warn- ing)			
6115	Service timer 1	Output A	Not used Option- dep.	Not used			
6116	Service timer 1	Reset	OFF ON	OFF			
6120 Service timer 2							
6121	Service timer 2	Enable	OFF ON	ON		Designer's Reference Handbook	The timer is reset by ena- bling menu 6126. The menu automatically goes OFF.
6122	Service timer 2	Hours timer	0 hrs 9000 hrs	500 hrs			
6123	Service timer 2	Days tim- er	1 days 1000 days	365 days			

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6124	Service timer 2	Fail class	F1...F8	F2 (Warning)			
6125	Service timer 2	Relay output A	Not used Option-dep.	Not used			
6126	Service timer 2	Reset	OFF ON	OFF			

3.5.3 Alarm horn

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6130 Alarm horn							
6131	Alarm horn	ON time	0.0 sec 990.0 sec	20.0 sec		Designer's Reference Handbook	If the setting is adjusted to 0 s, the horn relay will be acti- vated continuously until the alarm is acknowledged.

3.5.4 Run coil setup

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6150 Run coil setup							
6151	Run coil setup	ON time	0.0 sec 600.0 sec	1.0 sec		Designer's Re- ference Hand- book	
6152	Run coil setup	Type	Pulse Continuous	Pulse		Designer's Re- ference Hand- book	Pulse: Reset for each start attempt. Continuous: High throughout all start at- tempts.

3.5.5 Running, start and stop

No.	Setting		Min. Max.	Facto- ry set- ting	Notes	Ref.	Description
6160 Run status							
6161	Run sta- tus	Timer	0.0 s 300.0 s	5.0 s		Designer's Reference Handbook	If a relay output is used, the re- lay in question must be set to "limit".
6162	Run sta- tus	Relay output A	Not used Option- dep.	Not used			
6163	Run sta- tus	Relay output B	Not used Option- dep.	Not used			
6164	Run sta- tus	Enable	OFF ON	OFF			
6170 Running feedback							
6171	Running feed- back	Teeth	0 teeth 500 teeth	0 teeth		Designer's Reference Handbook	Available running detection types: - Binary input - MPU input - Frequency - EIC (engine communication) - Multi-input 6 - Multi-input 7 - Multi-input 8 If menu 6171 is set to 0, the magnetic pickup (MPU) input is not active. If menu 6175 is set to 0.0, the oil pressure running feedback is not active.
6172	Running feed- back	Type	Binary input EIC	Fre- quency			
6173	Running feed- back	Run de- tect	0 RPM 4000 RPM	1000 RPM			
6174	Running feed- back	Remove starter	1 RPM 2000 RPM	400 RPM			
6175	Running feed- back	Oil pres- sure	0.0 bar 150.0 bar	0.0 bar			
6180 Starter							
6181	Starter	Start prepare	0.0 s 600.0 s	5.0 s		Designer's Reference Handbook	Menu 6185 and 6186 relate to using oil pressure as running feedback. If menu 6186 is set to 0.0, the oil pressure running feedback is disregarded.
6182	Starter	Ext. pre- pare	0.0 s 600.0 s	0.0 s			
6183	Starter	Start ON time	1.0 s 180.0 s	5.0 s			
6184	Starter	Start OFF time	1.0 s 99.0 s	5.0 s			

No.	Setting		Min. Max.	Facto- ry set- ting	Notes	Ref.	Description
6185	Starter	Type	Multi-in- put 6 Multi-in- put 8	Multi- input 6			
6186	Starter	Set point	0.0 bar 300.0 bar	0.0 bar			
6190 Start attempts							
6191	Start at- tempts	Set point	1 10	3		Designer's Reference Handbook	Number of start attempts.
6200 Shutdown override							
6201	Shut- down override	Attempts	1 10	7		Designer's Reference Handbook	Shutdown override turns all shutdowns into warnings. Only exception is overspeed and emergency stop.
6202	Shut- down override	Cooling down timer	0 s 9900 s	240 s			
6203	Shut- down override	Reset	OFF ON	OFF			
6210 Stop							
6211	Stop	Cooling down	0 s 9900 s	240 s		Designer's Reference Handbook	The extended stop timer starts when the running feedback dis- appears. During the delay time it is not possible to start the en- gine.
6212	Stop	Exten- ded stop	1.0 s 99.0 s	5.0 s			
6213	Stop	TYPE	Multi-in- put 6 EIC	Multi- input 6			
6214	Stop	Set point	0 deg. 482 deg.	0 deg.			
6220 Hz/V OK							
6221	HZ/V OK	Timer	1.0 s 99.0 s	5.0 s		Designer's Reference Handbook	The voltage and frequency have to be continuously within the lim- its during the delay timer before the breaker can be closed.

3.5.6 Breaker control

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6230 GB control							
6231	GB control	Close delay	0.0 s 30.0 s	2.0 s		Designer's Reference Handbook	Menu 6232 is for compact breakers (need to charge spring before closing).
6232	GB control	Load time	0.0 s 30.0 s	0.0 s			

3.5.7 Idle start

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6290 Idle running							
6291	Idle start	Start timer	0.0 min. 999.0 min.	300.0 min.		Designer's Reference Handbook	
6292	Idle start	Enable start	OFF ON	OFF			
6293	Idle stop	Stop timer	0.0 min. 999.0 min.	300.0 min.			
6294	Idle stop	Enable stop	OFF ON	OFF			
6295	Idle active	Relay output A	Not used Option-dep.	Not used			
6296	Idle active	Idle running	OFF ON	OFF			

3.5.8 Engine heater

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6320 Engine heater							
6321	Engine heater	Set point	20 deg. 250 deg.	40 deg.		Designer's Reference Handbook	Heater function for standstill. Type: - Multi-input 6 - Multi-input 7 - Multi-input 8 - EIC
6322	Engine heater	Relay output A	Not used Option- dep.	Not used			
6323	Engine heater	Type	Multi-inp 6 EIC	Multi-inp 6			
6324	Engine heater	Hystere- sis	1 deg. 70 deg.	3 deg.			
6325	Engine heater	Enable	OFF ON	OFF			

3.5.9 Cooling ventilation

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6460 Max. ventilation							
6461	Max. ventila- tion	Set point	20 deg. 250 deg.	90 deg.		Designer's Ref- erence Hand- book	Ventilation fan control.
6462	Max. ventila- tion	Relay out- put A	Not used Option-dep.	Not used			
6463	Max. ventila- tion	Hysteresis	1 deg. 70 deg.	5 deg.			
6464	Max. ventila- tion	Enable	OFF ON	OFF			

3.5.10 Summer/winter time

No.	Setting		Min. Max.	Factory set- ting	Notes	Ref.	Description
6490 Summer/winter time							
6491	Sum/win time	Enable	OFF ON	OFF		Designer's Ref- erence Hand- book	The summer/winter time change follows the mainland Europe rules.

3.5.11 Fuel transfer pump logic

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6550 Fuel pump logic							
6551	Fuel pump logic	Pump start	0 % 100 %	20 %		Designer's Refer- ence Handbook	Type: - Multi-input 6 - Multi-input 7 - Multi-input 8
6552	Fuel pump logic	Pump stop	0 % 100 %	80 %			
6553	Fuel pump logic	Fill check time	0.1 s 300.0 s	60.0 s			
6554	Fuel pump logic	Relay out- put A	Not used Option-dep.	Not used			
6555	Fuel pump logic	Set point	Multi-inp 6 Multi-inp 8	Multi-inp 6			
6556	Fuel pump logic	Fail class	F1...F8	Warning (F2)			

3.5.12 Alarm jump

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
6900 Alarm jump							
6901	Alarm jump	Enable	OFF ON	ON		Designer's Reference Handbook	Selection of jump to alarm list view on the display if an alarm appears (ON), or stay at present view (OFF).

3.5.13 Command timers



There are four identical command timers in the unit, menu 6960-6996, but only command timer 1 is displayed in this manual.

No.	Setting	Min. Max.	Factory setting	Notes	Ref.	Description
6960 Command start/stop timer 1						
6961	Start timer 1 days	Set point	MO MO-TU- WE-TH- FR-SA-SU	OFF	Designer's Reference Hand-book	Selections are: MO TU WE TH FR SA SU MO-TU-WE-TH MO-TU-WE-TH-FR SA-SU MO-TU-WE-TH-FR-SA-SU
6962	Start timer 1 hour	Set point	0 23	10	Designer's Reference Hand-book	
6963	Start timer 1 min	Set point	0 59	0	Designer's Reference Hand-book	
6964	Stop timer 1 days	Set point	MO MO-TU- WE-TH- FR-SA-SU	MO-TU- WE-TH- FR-SA-SU	Designer's Reference Hand-book	Selections are: MO TU WE TH FR SA SU MO-TU-WE-TH MO-TU-WE-TH-FR SA-SU MO-TU-WE-TH-FR-SA-SU
6965	Stop timer 1 hour	Set point	0 23	10	Designer's Reference Hand-book	
6966	Stop timer 1 min	Set point	0 59	0	Designer's Reference Hand-book	



Start/stop timers can be used in M-Logic.

3.6 System parameters, mains setup

3.6.1 Test

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
7040 Test running							
7042	Test	Test time	0.0 min. 999.0 min.	5.0 min.		Designer's Reference Handbook	Available test types: - Simple (engine run only) - Full (disconnects mains)
7043	Test	Return mode	Semi-auto mode Auto mode	Auto mode			
7044	Test	Test type	Simple test Full test	Simple test			

3.6.2 Mains failure

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
7060 U Mains Failure							
7061	U Mains failure	Fail. de- lay	0.5 s 990.0 s	5.0 s		Designer's Reference Handbook	Menus 7063 and 7064 relate to nominal settings. Menu 7066 refers to the mean value of the meas- ured voltage.
7062	U Mains failure	Mains OK delay	10 s 9900 s	60 s			
7063	U Mains failure	U<	80 % 100 %	90 %			
7064	U Mains failure	U>	100 % 120 %	110 %			
7065	U Mains failure	Mains fail. con- trol	Start eng. + open MB Start en- gine	Start eng. + open MB			
7066	U Mains failure	U unbal- ance	2 % 100 %	100 %			
7070 f Mains Failure							
7071	f Mains failure	Fail. de- lay	0.5 s 990.0 s	5.0 s		Designer's Reference Handbook	Menus 7073 and 7074 relate to nominal settings.
7072	f Mains failure	Mains OK delay	10 s 9900 s	60 s			
7073	f Mains failure	f<	80.0 % 100.0 %	95.0 %			
7074	f Mains failure	f>	100.0 % 120.0 %	105.0 %			
7080 MB control							
7081	MB con- trol	Mode shift	OFF ON	OFF		Designer's Reference Handbook	Mode shift allows switch- ing to AMF mode.
7082	MB con- trol	MB close delay	0.0 s 30.0 s	0.5 s			
7085	MB con- trol	Load time	0.0 s 30.0 s	0.0 s			

3.7 System parameters, external communication

3.7.1 External communication

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
7510 External communication							
7511	Ext. communi- cation	ID	1 247	3		Option H2	The mode ASCII is used for modem communication (ASCII: 7 data bit, RTU: 8 data bit).
7512	Ext. communi- cation	Mode	RTU ASCII	RTU		Option H2	

3.8 System parameters, engine interface communication

3.8.1 Engine interface communication

No.	Setting		Min. Max.	Fac- tory set- ting	Notes	Ref.	Description
7560 Engine I/F							
7561	En- gine I/F	En- gine type	OFF DDEC EMR JDEC Iveco Perkins Caterpillar Volvo Penta Volvo Penta EMS 2 Scania EMS Scania EMS 2 MDEC 2000/4000 M. 302 MDEC 2000/4000 M. 303 MTU ADEC Cummins Generic J1939 MTU J1939 Smart Con- nect	OFF		Op- tion H5	Please choose MDEC 2000/4000 M.303 when M.201 or M.304 is required. Menu 7562 is only applicable when MTU ADEC is selected as engine type. Menu 7563 is for enabling the EIC commands transmission. Menu 7564: When set to “ON”, up to 19 extra views (of 3 lines) are added to the 15 original V1 views (of 3 lines). These extra views are displaying all the present engine com. values broadcasted on this CAN communication when this function is set to “ON”.
7562	CAN- open ID	Node ID	0 16	0			
7563	EIC Con- trols	Ena- ble	OFF ON	ON			
7564	EIC Auto view	Ena- ble	OFF ON	OFF			

3.9 System parameters, setup menu

3.9.1 Password config.

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
9110 Password							
9111	User password	Setting	0 32000	2000		Designer's Reference Handbook	It is recommended to change the password levels of the user, service and master password if access to parameter settings must be restricted
9112	Service password	Setting	0 32000	2001			
9113	Master password	Setting	0 32000	2002			

3.9.2 AC config.

This menu is used to choose the AC configuration.

No.	Setting		Description
9130 AC configuration			
9130	AC configuration	Setting	Selections: • 3 phase L1L2L3 • 2 phase L1L3 • 2 phase L1L2 • 1 phase L1

Phase angles:	Description
3 phase L1L2L3	120 degrees with neutral.
2 phase L1L3	180 degrees (split phase, neutral in the centre).
2 phase L1L2	120 degrees with neutral.
1 phase L1	Single phase with phase-neutral.

3.9.3 Display control

This menu is used to control parameters for the display on the unit.

No.	Setting	Description
9150 Backlight dim		
9151	Backlight level	Sets the light intensity for the display.
9152	Contrast level	Sets the contrast for the display.

3.10 System parameters, RMI inputs

3.10.1 RMI 6



RMI 6 settings are only accessible in the utility software.

No.	Setting	Min. Max.	Factory set- ting	Notes	Ref.	Description
10460 RMI 6 type						
10460	RMI 6 type	Sensor type 1 Configurable RMI	Sensor type 1		Designer's Refer- ence Handbook	Selections are: -Sensor type 1 -Sensor type 2 -Sensor type 3 -Configurable RMI
10470 RMI 6 input set point 1						
10470	RMI 6 inp. setp. 1	0 Ohm 2500 Ohm	10 Ohm		Designer's Refer- ence Handbook	Configurable RMI curve.
10480 RMI 6 output set point 1						
10480	RMI 6 outp. setp. 1	-49 482	40		Designer's Refer- ence Handbook	Configurable RMI curve.
10490 RMI 6 input set point 2						
10490	RMI 6 inp. setp. 2	0 Ohm 2500 Ohm	44.9 Ohm		Designer's Refer- ence Handbook	Configurable RMI curve.
10500 RMI 6 output set point 2						
10500	RMI 6 outp. setp. 2	-49 482	50		Designer's Refer- ence Handbook	Configurable RMI curve.
10510 RMI 6 input set point 3						
10510	RMI 6 inp. setp. 3	0 Ohm 2500 Ohm	81 Ohm		Designer's Refer- ence Handbook	Configurable RMI curve.
10520 RMI 6 output set point 3						
10520	RMI 6 outp. setp. 3	-49 482	60		Designer's Refer- ence Handbook	Configurable RMI curve.
10530 RMI 6 input set point 4						
10530	RMI 6 inp. setp. 4	0 Ohm 2500 Ohm	134.7 Ohm		Designer's Refer- ence Handbook	Configurable RMI curve.
10540 RMI 6 output set point 4						
10540	RMI 6 outp. setp. 4	-49 482	80		Designer's Refer- ence Handbook	Configurable RMI curve.
10550 RMI 6 input set point 5						
10550	RMI 6 inp. setp. 5	0 Ohm 2500 Ohm	184 Ohm		Designer's Refer- ence Handbook	Configurable RMI curve.
10560 RMI 6 output set point 5						

No.	Setting	Min. Max.	Factory set- ting	Notes	Ref.	Description
10560	RMI 6 outp. setp. 5	-49 482	100		Designer's Refer- ence Handbook	Configurable RMI curve.
10570 RMI 6 input set point 6						
10570	RMI 6 inp. setp. 6	0 Ohm 2500 Ohm	200 Ohm		Designer's Refer- ence Handbook	Configurable RMI curve.
10580 RMI 6 output set point 6						
10580	RMI 6 outp. setp. 6	-49 482	110		Designer's Refer- ence Handbook	Configurable RMI curve.
10590 RMI 6 input set point 7						
10590	RMI 6 inp. setp. 7	0 Ohm 2500 Ohm	210 Ohm		Designer's Refer- ence Handbook	Configurable RMI curve.
10600 RMI 6 output set point 7						
10600	RMI 6 outp. setp. 7	-49 482	115		Designer's Refer- ence Handbook	Configurable RMI curve.
10610 RMI 6 input set point 8						
10610	RMI 6 inp. setp. 8	0 Ohm 2500 Ohm	220 Ohm		Designer's Refer- ence Handbook	Configurable RMI curve.
10620 RMI 6 output set point 8						
10620	RMI 6 outp. setp. 8	-49 482	120		Designer's Refer- ence Handbook	Configurable RMI curve.

3.10.2 RMI 7



RMI 7 settings are only accessible in the utility software.



Menus 10630-10790 equal the settings for RMI 6 (10460-10620).

3.10.3 RMI 8



RMI 8 settings are only accessible in the utility software.



Menus 10800-10960 equal the settings for RMI 6 (10460-10620).

3.10.4 RMI 58



RMI 58 settings are only accessible in the utility software.

No.	Setting	Min. Max.	Factory setting	Notes	Ref.	Description
11340 RMI 58 type						
11340	RMI 58 type	Sensor type 1 Sensor type 3	Sensor type 1		Designer's Reference Handbook	Selections are: -Sensor type 1 -Sensor type 2 -Sensor type 3

3.10.5 RMI 59



RMI 59 settings are only accessible in the utility software.



Menu 11350 equals the settings for RMI 58 (11340).

3.10.6 Multi-input selections

No.	Setting	Min. Max.	Factory setting	Notes	Ref.	Description
10970 Engineering units						
10970	Engineering units	Bar/Celsius Psi/Fahrenheit	Bar/Celsius			
10980 Multi-input configuration 6						
10980	Multi inp. conf. 6	4-20 mA Binary	Binary			Possible selections: 4-20 mA Pt100 Pt1000 RMI oil pressure RMI water temp RMI fuel level Binary
10990 Multi-input configuration 7						
10990	Multi inp. conf. 7	4-20 mA Binary	Binary			Possible selections: 4-20 mA Pt100 Pt1000 RMI oil pressure RMI water temp RMI fuel level Binary
11000 Multi-input configurable 8						
11000	Multi inp. conf. 8	4-20 mA Binary	Binary			Possible selections: 4-20 mA Pt100 Pt1000 RMI oil pressure RMI water temp RMI fuel level Binary
11300 Multi-input configurable 58						
11300	Multi inp. conf. 58	4-20 mA Binary	Binary			Possible selections: 4-20 mA Pt100 Pt1000 RMI oil pressure RMI water temp RMI fuel level Binary
11310 Multi-input configurable 59						

No.	Setting	Min. Max.	Factory setting	Notes	Ref.	Description
11310	Multi inp. conf. 59	4-20 mA Binary	Binary			Possible selections: 4-20 mA Pt100 Pt1000 RMI oil pressure RMI water temp RMI fuel level Binary

3.10.7 Analogue unit input scaling

No.	Setting	Min. Max.	Factory setting	Notes	Ref.	Description
11010 Analogue unit input scale 6						
	Analogue unit input scale 6	Set point	None 1/1 Ohm 1/10	mA 1/1		



The same settings apply to menus 11020, 11030, 11320 and 11330.